

VIBRATING EGG EASYTOYS

EGG PLAY



User manual

CONTROL

- 1) Press the button on the egg to put it into standby mode.
- 2) Subsequent short presses of the button turn on and change vibration modes.
- 3) To turn it off, long press and hold the button for 3 seconds.
- 4) To use the remote control, put the egg in standby mode and press the power button on the remote.
- 5) Use the + and - buttons to toggle the individual programs.

MAINTENANCE

After each use, rinse the egg with lukewarm water and soapy detergent.

You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The egg is **water resistant**, so maintenance is very easy.

The egg can be splashed with water, but you **MUST NOT immerse it in water!**

Waterproof means that you could completely submerge the product in water and enjoy water play.

Due only to the water resistance of the product, this is not possible in this case.

LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The egg is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find a vibrating egg, remote control, CR 2032 battery and USB cable for charging.