

## Tondeuse cheveux

### CONSEILS DE SÉCURITÉ

- Votre appareil est conforme aux normes et réglementations applicables (Directives Bassa Tension, Compatibilité Electromagnétique, Environnement...).
- Vérifiez que la tension de votre installation électrique correspond à celle de votre appareil.
- Toute erreur de branchement peut causer des dommages irréversibles non couverts par la garantie.
- L'insécurité de l'appareil et son utilisation doit toutefois être conforme aux normes de sécurité dans votre pays.
- Cet appareil peut être utilisé par des enfants âgés de 8 ans et plus et des personnes ayant des capacités physiques, sensorielles ou mentales réduites ou un manque d'expérience ou de connaissances, s'ils sont recus un encadrement ou des instructions concernant l'utilisation de l'appareil avec toute sécurité et comprennent les risques encourus. Les enfants ne doivent pas utiliser l'appareil sans surveillance. Il convient de surveiller les enfants pour s'assurer qu'ils ne jouent pas avec l'appareil.
- S'il existe de l'alimentation et son utilisation doit toutefois être conforme aux normes de sécurité dans votre pays.
- Cet appareil peut être utilisé par des enfants âgés de 8 ans et plus et des personnes ayant des capacités physiques, sensorielles ou mentales réduites ou un manque d'expérience ou de connaissances, s'ils sont recus un encadrement ou des instructions concernant l'utilisation de l'appareil avec toute sécurité et comprennent les risques encourus. Les enfants ne doivent pas utiliser l'appareil sans surveillance. Il convient de surveiller les enfants pour s'assurer qu'ils ne jouent pas avec l'appareil.

MISE EN GARDE : Maintenir l'appareil au sec.

MISE EN GARDE : Pour le rechargeur de la batterie, utilisez uniquement l'adaptateur fourni avec l'appareil.

►►► Unité d'alimentation amovible 0935. L'appareil doit être exclusivement utilisé avec le bloc d'alimentation fourni 0935.

►►► Si les broches des pièces de la fiche sont endommagées, le bloc d'alimentation doit être mis au rebut.

►►► Le câble ou le cordon flexible externe de transformateur ne peut être remplacé; si le cordon est endommagé ou ne fonctionne pas, le transformer doit être remplacé.

Cet appareil contient des batteries qui ne peuvent être remplacées que par des personnes qualifiées.

• Cet appareil n'est pas prévu pour être utilisé par des personnes (y compris les enfants) dont les capacités physiques, sensorielles ou mentales sont réduites, ou des personnes dénuées d'expérience ou de connaissance, sauf si elles ont pu bénéficier, par l'intermédiaire d'une personne responsable de leur sécurité, d'un encadrement ou d'instructions préalables concernant l'utilisation de l'appareil. Il convient de surveiller les enfants pour s'assurer qu'ils ne jouent pas avec l'appareil.

►►► Si le câble d'alimentation est endommagé, il doit être remplacé par le fabricant, son service après vente ou des personnes de qualification similaire afin d'éviter un danger.

MISE EN GARDE : Maintenir l'appareil au sec.

MISE EN GARDE : Pour le rechargeur de la batterie, utilisez uniquement l'adaptateur fourni avec l'appareil.

►►► Unité d'alimentation amovible 0935. L'appareil doit être exclusivement utilisé avec le bloc d'alimentation fourni 0935.

►►► Si les broches des pièces de la fiche sont endommagées, le bloc d'alimentation doit être mis au rebut.

►►► Le câble ou le cordon flexible externe de transformateur ne peut être remplacé; si le cordon est endommagé ou ne fonctionne pas, le transformer doit être remplacé.

Cet appareil contient des batteries qui ne peuvent être remplacées que par des personnes qualifiées.

• Cet appareil n'est pas prévu pour être utilisé par des personnes (y compris les enfants) dont les capacités physiques, sensorielles ou mentales sont réduites, ou des personnes dénuées d'expérience ou de connaissance, sauf si elles ont pu bénéficier, par l'intermédiaire d'une personne responsable de leur sécurité, d'un encadrement ou d'instructions préalables concernant l'utilisation de l'appareil. Il convient de surveiller les enfants pour s'assurer qu'ils ne jouent pas avec l'appareil.

►►► Utilisez toujours votre appareil et contactez un Centre Service Agréé si :

- Si le câble n'est pas normalisé.

- L'appareil doit être débranché.

- Si l'appareil ne fonctionne pas.

- Si l'appareil est défectueux.

- Si l'appareil est endommagé.

- Ne pas utiliser le cordon en tirant sur le cordon, mais en tirant par la prise.

- Ne pas utiliser de prolongateur électrique.

- Ne pas nettoyer avec des produits abrasifs ou corrosifs.

- Ne pas utiliser par température supérieure à 35°C.

- Nettoyer les lames de la tondeuse avec la brosse fournie après chaque utilisation.

GARANTIE

Votre appareil est destiné à un usage domestique seulement.

Il ne peut être utilisé à des fins professionnelles.

La garantie devient nulle et invalide en cas d'utilisation incorrecte.

MISE EN GARDE : avant toute utilisation, veillez à bien recharger votre appareil. Cet appareil ne fonctionne pas sur secteur.

PARTICIPIONS À LA PROTECTION DE L'ENVIRONNEMENT !

►►► Votre appareil contient de nombreux matériaux valorisables ou recyclables.

Confiez celui-ci dans un point de collecte ou à défaut dans un centre service agréé pour que son traitement soit effectué.

Recyclage des batteries.

Pour le retrait des accus Li-ION, déchargez complètement les accus avant démontage. Ouvrir les bouteilles de l'appareil avec un outil, couper les connexions, recycler les accus de façon sûre.

►►► Pour plus d'informations, voir les instructions de l'appareil.

►►► Poins de collecte sur www.qualidemande.fr

Ces instructions sont également disponibles sur notre site internet www.rowenta.com

EN Read the instructions before use to avoid any danger due to misuse.

## Hair clipper

### SAFETY INSTRUCTIONS

• For your safety, this appliance complies with the applicable standards and regulations (Low Voltage Directive, Electromagnetic Compatibility, Environmental...).

• Check that the voltage of your electricity supply matches the voltage of your appliance. Any error when connecting the appliance can cause irreparable harm, not covered by the guarantee.

• The installation of the unit and its use must however comply with the standards for your country.

• This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user care must not be carried out by children without supervision.

• If the plug or power cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

• WARNING: Keep the appliance dry.

• WARNING: For the purposes of recharging the battery, only use the detachable supply unit provided with this appliance.

►►► Detachable supply unit 0935 : The appliance must only be used with the power pack supplied 0935.

►►► If the power pack is damaged, the plug-power supply shall be scrapped.

• The external flexible cable or cord of this transformer cannot be replaced; if the cord is damaged or does not work, the transformer shall be scrapped.

• This appliance contains batteries that are only replaceable by skilled persons.

• This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

• Children should be supervised to ensure that they do not play with the appliance.

• Stop using your appliance and contact an Authorised Service Centre if:

- the plug or power cord is damaged;

- the unit does not work correctly;

- The appliance must be unplugged:

- before cleaning and maintenance procedures.

- as soon as you have finished using it.

• If the power pack is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

• WARNING: Keep the appliance dry.

• WARNING: For the purposes of recharging the battery, only use the detachable supply unit provided with this appliance.

►►► Detachable supply unit 0935 : The appliance must only be used with the power pack supplied 0935.

►►► If the power pack is damaged, the plug-power supply shall be scrapped.

• The external flexible cable or cord of this transformer cannot be replaced; if the cord is damaged or does not work, the transformer shall be scrapped.

• This appliance contains batteries that are only replaceable by skilled persons.

• This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

• Children should be supervised to ensure that they do not play with the appliance.

• Stop using your appliance and contact an Authorised Service Centre if:

- the plug or power cord is damaged;

- the unit does not work correctly;

- The appliance must be unplugged:

- before cleaning and maintenance procedures.

- as soon as you have finished using it.

• If the power pack is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

• WARNING: Keep the appliance dry.

• WARNING: For the purposes of recharging the battery, only use the detachable supply unit provided with this appliance.

►►► Detachable supply unit 0935 : The appliance must only be used with the power pack supplied 0935.

►►► If the power pack is damaged, the plug-power supply shall be scrapped.

• The external flexible cable or cord of this transformer cannot be replaced; if the cord is damaged or does not work, the transformer shall be scrapped.

• This appliance contains batteries that are only replaceable by skilled persons.

• This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

• Children should be supervised to ensure that they do not play with the appliance.

• Stop using your appliance and contact an Authorised Service Centre if:

- the plug or power cord is damaged;

- the unit does not work correctly;

- The appliance must be unplugged:

- before cleaning and maintenance procedures.

- as soon as you have finished using it.

• If the power pack is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

• WARNING: Keep the appliance dry.

• WARNING: For the purposes of recharging the battery, only use the detachable supply unit provided with this appliance.

►►► Detachable supply unit 0935 : The appliance must only be used with the power pack supplied 0935.

►►► If the power pack is damaged, the plug-power supply shall be scrapped.

• The external flexible cable or cord of this transformer cannot be replaced; if the cord is damaged or does not work, the transformer shall be scrapped.

• This appliance contains batteries that are only replaceable by skilled persons.

• This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

• Children should be supervised to ensure that they do not play with the appliance.

• Stop using your appliance and contact an Authorised Service Centre if:

- the plug or power cord is damaged;

- the unit does not work correctly;

- The appliance must be unplugged:

- before cleaning and maintenance procedures.

- as soon as you have finished using it.

• If the power pack is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

• WARNING: Keep the appliance dry.

• WARNING: For the purposes of recharging the battery, only use the detachable supply unit provided with this appliance.

►►► Detachable supply unit 0935 : The appliance must only be used with the power pack supplied 0935.

►►► If the power pack is damaged, the plug-power supply shall be scrapped.

• The external flexible cable or cord of this transformer cannot be replaced; if the cord is damaged or does not work, the transformer shall be scrapped.

• This appliance contains batteries that are only replaceable by skilled persons.

• This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

• Children should be supervised to ensure that they do not play with the appliance.

• Stop using your appliance and contact an Authorised Service Centre if:

- the plug or power cord is damaged;

- the unit does not work correctly;

- The appliance must be unplugged:

- before cleaning and maintenance procedures.

- as soon as you have finished using it.

• If the power pack is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

• WARNING: Keep the appliance dry.

• WARNING: For the purposes of recharging the battery, only use the detachable supply unit provided with this appliance.

►►► Detachable supply unit 0935 : The appliance must only be used with the power pack supplied 0935.

►►► If the power pack is damaged, the plug-power supply shall be scrapped.

• The external flexible cable or cord of this transformer cannot be replaced; if the cord is damaged or does not work, the transformer shall be scrapped.

• This appliance contains batteries that are only replaceable by skilled persons.

• This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

• Children should be supervised to ensure that they do not play with the appliance.

• Stop using your appliance and contact an Authorised Service Centre if:

- the plug or power cord is damaged;

- the unit does not work correctly;

- The appliance must be unplugged:

- before cleaning and maintenance procedures.

