

SATISFYER SNIPER PENIS RING

CONTROL

- 1) Hold the power button for 2 seconds to turn on.
- 2) Short presses of the same button change individual vibration and pulsation rhythms.
- 3) To turn off, press the power button for 2 seconds.

MAINTENANCE

After each use, rinse the ring with lukewarm water and soap.
You can also use a sex toys cleaner, which additionally helps to remove microscopic dirt.
Just spray the product, let it work for about 1 minute and then dry it with a lint-free towel or cloth.

WATER RESISTANCE

The ring is waterproof, so its maintenance is very easy.
Splashing water can fall on it, but you can safely submerge it in water and enjoy some water games.

LUBRICATION

Use only WATER BASED lubricants. Other lubricating gels could damage the surface of the device and it would then become sticky.

PROPULSION AND CHARGING

The ring is powered by an integrated Li-on battery, which is approximately half charged from the time of production.

however, we recommend fully charging it before first use.

Charge the battery using the included USB cable, which you can plug into a phone adapter, a PC or a power bank. When charging, the LED blinks, and when fully charged, the LED indicator lights up permanently.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGE CONTENTS

Vibration ring, magnetic USB cable for charging.