


# 1. Meet ROMP Switch X



## 2. Enjoy



Before using, we recommend applying water-based lube onto the stimulation head as well as onto your clitoris.

Hold the (+) button for 2 secs to turn ROMP Switch X on.



Position the stimulation head on your clitoris with light pressure. Make it comfortable with your body and find the spot that feels good for you.


Briefly press the function button to cycle through 6 intensity levels ... and again... and again... just sit back and enjoy the ride.

Hold the (-) button for 2 secs, and ROMP Switch X will turn off.

## 3. Play Ideas



ROMP Switch X is designed to be played with by a couple or solo, whether it's a gentle tease or an earth-shaking climax... Need some inspiration? Here are some play ideas to help you get in the mood...



Use your ROMP Switch X to stimulate nipples and inner thighs to tease and tantalize your partner - or yourself.

Use your ROMP Switch X on your clitoris and ROMP Hype internal vibrator simultaneously for double the pleasure.

Your partner will enjoy using ROMP Switch X on you during sex, so hand over control and see where it takes you.

## 4. Clean



Remove the stimulation head.



ROMP Switch X is splashproof. You can clean the stimulation head with warm water and toy cleaner. You can also clean beneath the stimulation head with a cotton swab.



You can clean the device with a damp cloth.

Place the stimulation head back again and ROMP Switch X is ready for a new pleasure party.

## 5. Batteries



ROMP Switch X needs a power-up?

Open ROMP Switch X by sliding the battery compartment.



Take out the old batteries and give ROMP Switch X some new life with new ones. Watch out for the +/- signs.



ROMP Switch X is now full of energy and ready to go again!

## 6. Safety Instructions

### WARNING

Sold as a novelty product only. Not suitable for medical purposes. Only use the product for the intended purpose. Keep out of reach of children. If you are under a physician's care and/or have a condition requiring the use of any medical device, please consult your physician before using this product. Stop using the product immediately if you experience any skin irritations, pain or discomfort and consult your physician. This product can be used by adults only. Persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the product in a safe way and understand the hazards involved. Children shall not play with the product. Cleaning and user maintenance shall not be done by children. Do not use on swollen or inflamed areas of skin. Remove piercings or jewellery in the genital area before use. Always clean the product before and after use according to the instructions given in the manual. To avoid damage to the product, the product and its battery must not be exposed to temperatures above 45°C, be dismantled mechanically or electrically damaged. Sharing sex toys may transmit sexual diseases. Do not share your sex toys with users other than your partner. Use protective measures with your partner if necessary. Do not use the toy if you detect any cracks or signs of degradation in the cover material. This product is not designed for anal use. Do not use anally! To prevent stains, do not place the soft side of your product on an absorbent surface. Check the charging device and the product regularly for damage and do not use in any case of damage. Magnetic fields can influence mechanical and electronic components such as pacemakers. Do not use the product directly over a pacemaker. Contact your physician for more information. Keep cards with magnetic stripes (such as credit cards) away from the product, as they may be damaged by the product's magnet. If your product appears to be functioning abnormally, turn it off and consult the support section on our website.

### CHARGING

Do not disassemble, puncture, modify, drop, throw or cause other unnecessary shocks to the batteries. Do not charge non-rechargeable batteries. Do not put batteries in your mouth. If swallowed, contact your local physician immediately. Use only AAA battery. Do not use batteries, or charge rechargeable batteries, that appear to be leaking, discoloured, rusty, deformed, emit an odour or are otherwise abnormal.

### FOR OPTIMAL USE OF THE PRODUCT, PLEASE FOLLOW THE FOLLOWING GUIDELINES

Store in a secure, dry place without exposure to direct sunlight. We recommend using a water-based lubricant with your product. Do not use silicone-based lubricants, do not use perfume, alcohol-based lubricants, gels or massage oils with the product. Do not use silicone-based lubricants with silicone products.

### NOTE ON BATTERIES

European regulations require that we provide the following information: Batteries and rechargeable batteries must not be disposed of in household waste. As an end user, you are legally required to return used batteries. Please use official collection facilities such as the collection points provided by public waste management authorities to do so. You can also return used batteries that we carry or have carried as new batteries to us. Please contact us at [care@romp.toys](mailto:care@romp.toys). To prevent short circuits, the poles of lithium batteries should be taped before returning. For safety reasons, we ask you not to send the batteries to us by mail and refer you to the regulations for sending hazardous goods provided by mail carriers. If the batteries are permanently installed in the product, please do not try to remove them yourself. This may cause permanent damage to the device. Your obligations as a customer are otherwise regulated by the WEEE Directive and the national implementation law. Please observe the information in the manual and the safety instructions to prevent waste and littering. Used batteries contain harmful substances that can damage the environment or your health if they are not stored or disposed of properly. In particular, this applies to the improper handling of lithium batteries. Batteries also contain important raw materials such as iron, zinc, manganese and nickel and can be recycled. Separate collection allows these raw materials to be recycled and prevents negative impacts on the environment and human health from released pollutants. The sign with the crossed-out waste bin means that you must not dispose of batteries and accumulators with household waste. If the legal requirements are present, this sign means that the following symbols and their meaning must be used when labeling the batteries:



Hg: Battery contains more than 0.0005 percent mercury by mass

Pb: Battery contains more than 0.004 percent lead by mass

Cd: Battery contains more than 0.002 percent cadmium by mass

### NOTES ON DISPOSAL OF ELECTRICAL EQUIPMENT

We would like to point out to owners of electrical equipment that old electrical equipment must be collected separately from municipal waste in accordance with applicable legal regulations. Batteries and accumulators that are not firmly enclosed in the old electrical equipment, as well as bulbs that can be removed from the equipment without being destroyed, must be separated from the old equipment in an anon-destructive way before being given to a collection point for proper disposal. Please refer to the separate instructions for the disposal of batteries. The symbol of a crossed-out waste bin shown below and affixed to old electrical equipment also indicates that the equipment must be collected separately:



According to the WEEE Directive and the national implementation law, as distributors of electrical equipment, we are required to take back certain waste electrical equipment free of charge. When you purchase a new electrical and electronic device, you can surrender an old electrical device that essentially performs the same functions as the new device to us free of charge. If your old electrical equipment is not larger than 25 centimeters in any dimension, you can also surrender it to us free of charge without purchasing a new device. Please contact us at [care@romp.toys](mailto:care@romp.toys). We will then arrange the return of the old electrical equipment. For safety reasons, we would like to ask you to refrain from shipping lighting equipment (such as bulbs). Please use the collection points provided by public waste management authorities to return lighting equipment or contact us directly at the aforementioned e-mail address. You can also return old electrical equipment to any of the collection points run by the public waste disposal authorities. You are making an important contribution to the reuse, recycling and other recovery of old appliances by sending your old equipment for separate collection in the proper collection groups. As the end user, you are responsible for deleting personal data from the used electrical equipment before handing it in for disposal. Please observe the information in the manual and safety instructions to prevent waste, and please check for possible repair options.

## 7. General Information

### CUSTOMER CARE

Model No.: RPBT2

### CONTENT OF DELIVERY

ROMP Switch X clitoral stimulator, 2x AAA batteries, Quick start guide, Safety Information

[care@romp.toys](mailto:care@romp.toys)  
[www.romp.toys](http://www.romp.toys)

### MANUFACTURER WARRANTY

WOW Tech Europe GmbH offers a voluntary manufacturer warranty for this product which applies in addition to the statutory warranty to which consumers are entitled towards their seller. Details about the manufacturer warranty can be found on the website [www.romp.toys](http://www.romp.toys).

### MANUFACTURED BY

SOLD BY WOW TECH EUROPE GMBH

Hermann-Blankenstein-Str. 5 - 10249 Berlin, Germany

Designed in Germany. Date of issue 06/2023 Partnumber: MA-00277