## **BLOOMY LOTUS**

## Mandatory Safety

- · Never use the product for the proposes other than listed on this manual.
- Read the instruction manual before using this product.
- Remove all packaging before use.
- Use only the power plug contained in the package to avoid damage to the product.
- · When unplugging the power adaptor, set your hand on the adaptor body instead of pulling the cord.
- If the unit will not be used for an extended period or needs to be relocated, unplug the AC adaptor, dispose of the water and clean the unit before storage.
- Avoid moving the unit while in use, or carefully holding the whole product with base.
- The precautions listed in this manual are to ensure safe and proper use of this product by the user, and to avoid any danger or loss that might occur to the user or others.
- "WARNING" contains important safety instructions. Be sure to follow these instructions.

## Warning



• This device is not intended for use by persons with reduced physical or cognitive capacities without the necessary experience or knowledge, unless they have been trained to use the device correctly by a person responsible for their safety and have understood the risks involved.



Stop using the product immediately and unplug the device once smoke, smell, unusual sounds or other anomalies occur



Do not modify, fix or dismantle this product, as fire, electric shock or damage



 When the product is at the end of its life, we recommend disposal at a collection point for the recycling of electrical and electronic equipment, rather than with household waste.



- · When this product remains unused for a long period of time, the main unit must be inplugged from the electrical socket and water removed. Otherwise electric shock malfunction may occur.
- This product must be disconnected from the power sources before cleaning and
- furniture. If essential oil dripping accidently occurs, wipe off immediately to avoid discoloration of the exterior of the product or the furniture.
- This product is not medical equipment. Directly inhaling the aroma mist from the spout is not recommended.
- If you have any special physical conditions, such as pregnancy, lung failure, cancer, epilepsy, or other illnesses, please consult your doctor before using essential oils. Stop using the product and open the windows for ventilation if you start to feel uncomfortable
- · Essential oils are highly concentrated and should always be handled with care, including the amount for each use.



- Do not handle the main unit and outlet with wet hands, or let water or other liquids spill onto them, as this may result in electric shocks.
- This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety.
- Do not let children use this product. Keep out of reach of children as electric shock and injury may occur. Children should be properly supervised to ensure that they will not play with this product.
- To avoid fire, electric shock, injury or damage, do not place the product in the areas
- Environments exposed to direct sunlight to high temperatures and keep away from sources of ignition.
- Pressurized objects and combustibles.

# Product Dimensions

Product name: Petite Acorn Main unit weight: 653g ± 5 % Model code: BL-029 Water tank capacity: 140ml Product size: Ø115mm(L) x 166mm(H) Coverage area: Up to 45m<sup>2</sup> Indoor Room-temperature tap Environment: water/mineral water Run time: 2 /4 /8 hours PP. Glass Design: USA Power input: DC24V / 12W Made in China

Manufacturer: Bloomy Lotus LLC

### Product Warranty

Thank you for your purchase. The products carry a limited 12-month warranty on manufacturer defects. Please contact your local distributor for after sales enquiries or product maintenance.

Proof of purchase will be required. Warranty does NOT cover:

- Damage of accessories due to often use /depreciation
- Damage due to abuse or improper use of the product
- Damage of non-household use (i.e natural disaster, commercial use)
- Fail to provide any proof of product damage & purchase

We reserves the right for final decision of free product maintenance provided within mentioning period and any other conditions

duct name:	Model no.:			
chno:	Point of purchase:			
e of purchase:		FC	$C \in$	A

# Troubleshooting

If you experienced unsatisfactory operations, please follow our troubleshooting guidelines Possible Cause Solution

- )		
Diffuser does not turn on/diffuser shuts off before set time is over.	No water in the water tank Power cord not connected correctly	Add water to water tank until it reaches the RED Maximum water marker. Disconnect power cord and re-connect carefully.
No mist or abnormal mist	Normal LED light but no mist.	1. Check the water level. The water level should not be higher than the red water marker. 2. Ensure that tap water or mineral water is added. 3. Defective mist chip, please contact your direct retailer.
	No mist when covered with lid.	Avoid placing the product on soft or uneven surfaces. This will block the air inlet at the bottom 2. Determine if the fan is working. If it is not working please contact your direct retailer.
	Mist chip with oil residue. Air inlet at the bottom of the diffuser is blocked?	Please follow instructions on cleaning and maintenance. Clean the air inlet. A partially blocked inlet may interfere with the level of mist output.
Water Leak	Temperature and humidity levels can cause the mist to quickly condense into droplets.	Adjust room temperature and humidity levels to compensate.

• Do not attempt to dismantle or repair the product by yourself. If the unit still does not operate satisfactorily, please contact your local distributor.

# BLOOMY LOTUS

USER'S MANUAL Petite Acorn

Thank you for purchasing this product.

# Overview

### Main body Glass outer cover 2. Inner lid Water tank Mist spout Ventilation hole 6. Water marker 7. Mist chip 8. Fan 9. Air inlet 10. LED light 11. Mist button, time setting 12. Light button, color setting 13. Working hour indicator 14. DC socket Power adapter -----**→**□ □ ·

# Operating Instructions

· Always place your diffuser on a firm, flat and level surface.



4. Directly add 3-5 drops o

natural essential oil into



5. Replace the inner lid.






6. Replace the glass outer

cover. Ensure the glass


cover and the base are

aligned.



power outlet.

Caution:



start the device and

switch the timer.

1. Be sure to hold the whole product with the base carefully when moving the product. Handle

2. The unit should be placed on a level solid surface. Do not place on carpets, rugs,

4. The water level should not exceed the water marker to avoid damage to this device.

For best result, we recommend that you use natural essential oil with this scent diffuser.



- The default rotating lights setting will start automatically while the device is in MIST mode.
- Press the Light button a first time to switch to "Light Blue"
- Press the Light button a second time to switch to "Candle Light".

- Press the Light button a fourth time to switch the "Green Light".



- 2. Factors affecting the mist amount:water,humidity,temperature, and air flow.
- 3. Automatically shut-off function when the diffuser detects the water is empty or when it is tipped over

8. Do not remove the covers during operation.

under a running tap or whilst plugged in.

# Setting Instructions

### Mist Button

- Press the button once to turn ON the unit. The default time is 2 hours, indicated by the "2H" green LED light.
- Press the button a second time and the working time is set to be 4 hours, indicated by the "4H" green LED light.
- · Press the button for the third time and the working time is set to be 8 hours intermittently, indicated by the "8H" green LED light. (5 mins ON and 5 mins OFF).
- · Press the button a fourth time to switch the diffuser OFF.

### Light Button

- Press the Light button a third time to switch the "Purple Light".

- Press the Light button a fifth time to switch the light OFF.



1. A slight difference in mist amount produced by different units is expected.

this product with care to avoid impacts or drops.

wooden/polished furniture or unstable surfaces.


Keep water away from Ventilation Hole and Air Inlet.

Artificial fragrance, flavor, or impurities might harm to the unit.

7. Always unplug the product from electrical socket when not in use.

## Always disconnect the AC adaptor from the device before cleaning.

Cleaning and Maintenance



Power off and disconnect

the device from the

4. Make sure the air duct

the air duct outlet).

outlet is not subject to

spilling, Pour water out


from the opposite side (of

power outlet.





Handle





- Never soak or wash this product directly as it may cause mechanical malfunction or danger.
- Never use acidic cleansing agents as it may cause malfunctions to the product. Use cotton swab to clean the unit after each use. Rinse with tap or spring water, then wipe
- The water tank must be cleaned before the essential oil is changed each time.

- Make sure no water will spit into the air duct outlet as it might break the electrical circuit.















