

PENIS SLEEVE BUMP SUPER STRIKER VIBRATING

User manual



CONTROL

- 1) Hold the power button for 2 seconds to turn on the sleeve. The LED will flash and the sleeve will start its first vibration mode.
- 2) Additional short presses of this button change the individual vibration and pulsation rhythms.
- 3) To turn it off, long press the power button again for 3 seconds.
- 4) To operate with the remote control, remove the plastic control from the silicone case and twist the bottom to open the battery compartment.
- 5) Insert them according to the poles marked in the battery compartment, close the remote control and return it to the case.
- 6) Now turn on the sleeve. Change the individual vibration and pulsation rhythms by short presses of the button on the controller.
- 7) To pause the vibrations, hold the button on the controller for 3 seconds.
- 8) Press it again briefly to start it again.
- 9) You do not need to turn the controller off, turn the sleeve off with its own button.

MAINTENANCE

After each use, rinse the sleeve with lukewarm water and soapy detergent.

You can also use an [erotic cleaner](#), which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The sleeve is **water resistant**, so maintenance is very easy.

The sleeve can be splashed with water, but you **MUST NOT immerse it in water!**

Waterproof means that you could completely submerge the product in water and enjoy water play.

Due only to the water resistance of the product, this is not possible in this case.

LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The sleeve is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently.

The remote control is powered by two LR44 batteries.

STORAGE

The package includes a penis sleeve, remote control, USB charging cable and 2 LR44 batteries.

PACKAGING CONTENTS

In the package you will find a vibrator, remote control and magnetic USB cable for charging.