

PENIS RING FIFTY SHADES OF GREY YOURS AND MINE



CONTROL

- 1) Press the on/off button for min. 3 seconds
- 2) To turn off, hold the on/off button for min. 3 seconds

MAINTENANCE

Rinse the ring with lukewarm water and soapy detergent after each use.

CAUTION! Remove the battery cartridge before washing the vibrating ring!

You can also use an erotic aid cleaner, which also helps to remove microscopic dirt.

Just spray the product, leave it on for about 1 minute and then dry it with a towel or cloth that does not leak fibers.

WATERPROOF

The vibrating ring is not waterproof or water resistant.

LUBRICATION

Use only water-based lubricants. Other lubricating gels could damage the surface of the aid and the lubricant will become sticky.

DRIVE AND CHARGING

The vibrating ring is powered by two G3A batteries.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find a vibrating ring containing 2 batteries, a satin pouch and 4 spare batteries type G3A.