




Description

The Ripple Smart Diffuser (RPL) that simultaneously works with Apple Homekit, Alexa, and the Google Assistant. You can control it wirelessly with your voice or the VOCOLinc app/Home app in multiple ways through 2.4GHz Wi-Fi network. It features a rainbow-spectrum mood light that allows you to choose the right color to best fit your mood or occasion. You can set schedules to turn it on/off just the way you want it. Use it to improve your health by getting better air and atmosphere quality.



1	Mist Button	Quick press to select mist speed level
2	Timer Button	Quick press to set mist timer(2H/4H/6H) Long press 10s to reset
3	Light Button	Quick press to turn on/off mood light Long press to change color



Factory Reset

Press and hold the Timer button for 10 seconds until the mood light starts to blink and then light up. The device is now in pairing mode. Follow the instructions to add this device to your 2.4GHz Wi-Fi network and the VOCOLinc/Home app.

What's Included:

- Ripple Smart Diffuser
- AC/DC Adapter
- User Manual

Specifications

Dimensions	112mm x 158mm
Weight	370g(with adaptor)
Input	AC 100-240V 50/60Hz
Output	DC 24V 0.65A
Rated Power	10W Max
Water Tank Capacity	220ML
Button Control	MIST & TIMER & LIGHT
Wireless Network	Wi-Fi 2.4GHz 802.11 b/g/n
Applicable Area	Best up to 323 sq.ft.
Mist Speed Level	2 - speed adjustable
Mood Light	RGB Rainbow Spectrum
Firmware update	OTA (VOCOLinc app)

Firmware Update

To gain better experience with VOCOLinc products, we strongly recommend that you update the firmware whenever updates with all the latest improvement and fixes are available:

- Open the VOCOLinc app.
- Press device icon to enter the main page.
- Look for "Firmware update" and then tap "Update" when you see a prompt.

* Only the devices that are currently reachable and have an available update will prompt firmware update notice.

* It is important to leave the VOCOLinc app running while it finishes updating the device.

DO NOT to minimize the app, close the app, or interrupt the update until the updates are successful to prevent problems.

Attention

- Max. work time: 8 hours
- The amount and intensity of mist produced varies according to water type, the amount of water, humidity, temperature, air currents. Therefore, it should not be considered as a fault.
- Use 100% natural water-soluble essential oils ONLY. Other oils that contain chemical ingredients, flavors or impurities may cause damage to the device.
- Before replacing with another essential oil, clean the water tank first.

Accidental Leakage

In the event of the unit being knocked over or tipped during use, please follow the steps below to avoid damage to the device:

- Unplug the device and remove cover.
- Pour out any remaining water from the water tank.
- Gently shake out the water and then dry it in open space for at least 24 hours.

Maintenance

After continuously running a cycle (8hours), or 3-5 days, clean the device following the steps below:

- Unplug the device and remove the cover.
- Pour out any remaining water from tank.
- Clean the device with warm water (add a few drops of dish washing detergent), and then wipe it gently with dry cloth.
- Do not use acids or enzymes detergents, as this may give off hazardous gas or cause malfunction. Be sure to use a mild detergent.
- If diffuser is not used for an extended period, drain water from the tank.

FCC Declaration

Caution:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may

cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

IC Declaration

Caution:

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

(1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device. In order to avoid the possibility of exceeding the ISED radio frequency exposure limits, human proximity to the antenna shall not be less than 20cm (8 inches) during normal operation.

KEEP YOUR QR CODE SAFE



Setup code
Code de Configuration


La description



Le diffuseur intelligent Ripple (RPL) qui fonctionne simultanément avec Apple Homekit, Alexa et l'Assistant Google. Vous pouvez le contrôler sans fil avec votre voix ou l'application VOCOLinc / l'application Home de plusieurs façons via le réseau Wi-Fi 2,4 GHz.

Il dispose d'une lumière d'ambiance à spectre arc-en-ciel qui vous permet de choisir la bonne couleur pour s'adapter au mieux à votre humeur ou à votre occasion. Vous pouvez définir des horaires pour l'activer / le désactiver comme vous le souhaitez. Utilisez-le pour améliorer votre santé en obtenant une meilleure qualité de l'air et de l'atmosphère.



1	Bouton de brume	Appuyez rapidement pour sélectionner le niveau de vitesse de brouillard
2	Bouton de minuterie	Appuyez rapidement pour régler la minuterie de brouillard (2H / 4H / 6H) Appuyez longuement sur 10 secondes pour réinitialiser
3	Bouton lumineux	Appuyez rapidement pour allumer / éteindre la lumière d'ambiance Appuyez longuement pour changer de couleur



Réinitialisation des paramètres d'usine

Appuyez sur le bouton Minuterie et maintenez-le enfoncé pendant 10 secondes jusqu'à ce que la lumière d'ambiance commence à clignoter, puis à s'allumer. L'appareil est maintenant en mode de couplage. Suivez les instructions pour ajouter cet appareil à votre réseau Wi-Fi 2,4 GHz et à l'application VOCOLinc / Home.

Ce Qui Est Inclus:

- FlowerBud Diffuseur intelligent
- Adaptateur CA/CD
- Manuel de l'utilisateur

Spécifications

Dimensions	112mm x 158mm
Poids	370g(Avec adaptateur)
Entrée	CA 100-240V 50/60Hz
Sortie	CD 24V 0.65A
Puissance Nominale	10W Max
Capacité du réservoir d'eau	220ML
Bouton de contrôle	MIST & TIMER & LIGHT
Réseau Sans Fil	Wi-Fi 2.4GHz 802.11 b/g/n
Zone Applicable	Optimale jusqu'à 323 pieds carrés
Niveau de vitesse de la brume	2 - Vitesse ajustable (Manuellement)
Lumière D'ambiance	Spectre de couleurs RGB
Mise à jour du Firmware	OTA (Application VOCOLinc)

Mise à Jour du Firmware

Pour une meilleure expérience d'utilisation des produits VOCOLinc, nous recommandons que vous mettiez à jour le firmware à chaque fois qu'une mise à jour avec les dernières améliorations et correctifs est disponible :

- Lancez l'application VOCOLinc.
- Appuyez sur l'icône du périphérique pour accéder à la page principale.
- Recherchez " Mise à jour du Firmware " et puis appuyez sur " Mettre à jour " lorsque vous voyez un message.

* Seuls les appareils actuellement disponibles et ayant une mise à jour disponible demanderont une mise à jour du firmware.

* Il est important de laisser l'application VOCOLinc en exécution pendant l'installation de la mise à jour. Ne sortez pas de l'application, la fermer ou interrompre la mise à jour jusqu'à ce que la mise à jour se termine pour éviter d'éventuels problèmes.

Attentions

- Temps de travail maximal : 8 heures
- La quantité et l'intensité de la brume produite varie en fonction du type de l'eau, la quantité, l'humidité, la température et les courants d'air. Cela par conséquent ne doit pas être considéré comme défaut.
- Utilisez UNIQUEMENT des huiles essentielles 100% pures et naturelles soluble dans l'eau. Les autres huiles contenant des ingrédients chimiques, aromes ou des impuretés peuvent causer des dommages à l'appareil.
- Avant de remplacer une huile essentielle par une autre, nettoyez d'abord le réservoir d'eau.

Fuite Accidentelle

En cas de chute ou renversement de l'appareil en cours d'utilisation, veuillez suivre les étapes ci-dessous pour éviter d'endommager l'appareil :

- Débranchez l'appareil et retirez le cache.
- Videz le réservoir de l'eau restant dans le réservoir.
- Secouez l'eau doucement puis laissez sécher dans un espace ouvert pendant 24 heures minimum.

Maintenance

Après un cycle continu de fonctionnement (8 heures), ou 3-5 Jours, nettoyez l'appareil en suivant les étapes ci-dessous :

- Débranchez l'appareil et retirez le cache.
- Videz l'eau restant dans le réservoir.
- Nettoyez l'appareil avec de l'eau tiède (Ajoutez quelques gouttes de lessive détergent). Puis essuyez avec un chiffon sec.
- N'utilisez pas de détergents acide ou enzymatique, sous risque de production de gaz ou causer un dysfonctionnement. Assurez-vous d'utiliser un détergent doux.
- Si le diffuseur n'est pas utilisé pendant une période prolongée, évacuez l'eau du réservoir.

IC Déclaration

Mise en garde:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Afin d'éviter la possibilité de dépasser les limites d'exposition aux fréquences radio de la ISED, la proximité humaine à l'antenne ne doit pas être inférieure à 20 cm (8 pouces) pendant le fonctionnement normal.



Works with   