

Dear customer!

Should you have any remarks or questions concerning the product, please do not hesitate to contact us: help@lionelo.com

Producer:

BrandLine Group Sp. z o.o.
ul. A. Kręglewskiego 1, 61-248 Poznań, Poland

Recommended working conditions

Humidity: 50 – 80 %
Temperature: 15 – 30°C (59 – 86°F)

IMPORTANT

Please read this operating manual before you start using the product to see its functions and use it in accordance with intended use.

A failure to follow the safety instructions and use at variance with the manual may lead to bodily injuries.

Keep this manual for future reference.

1. Do not repair or modify the device on your own. Only an authorized service technician is allowed to perform these operations.
2. This device is not a toy. Do not let children play with it. Keep the device out of reach of children.
3. The device can be used by children aged at least 3 and persons with limited physical, sensory or mental capabilities, as well as persons who lack suitable knowledge and experience in using the device as long as their actions are supervised or if they have been instructed on safe use of the device and related risks beforehand.
4. Cleaning and maintenance of the device can be performed by children aged at least 8 and when supervised. Keep this device and power cable out of reach of children below the age of 3.
5. The device is intended for home use only. The device is not designed for outdoor use. Do not use it for other purposes, at variance with its intended use.
6. Make sure the power cable does not hang on the edge of the table or top. Make sure the power cable does not contact hot elements. Do not pull it through sharp edges.
7. Connect the device only to the power outlet with earthing. Make sure the power cable has been correctly connected to the source of power.
8. When powering the device, make sure parameters of the source of power correspond to the parameters specified on the product label.
9. Regularly check the device for damage. Do not use the device if it is damaged. Do not try to repair the device on your own – contact the authorized service center. If the power cable is damaged, it should be replaced by the manufacturer to avoid hazards.
10. After use, during assembly, disassembly and cleaning, the device must be switched off and unplugged.

