MASTURBATOR PDX ELITE VIBRATING ANAL STROKER

Instructions for use:

- 1. Remove from the bottom of the vibrating bullet, where are inserted the batteries
- 2. Open the tube and remove the transparent safety label from the accumulator, then the contacts will be connected
- 3. Open the upper part in which the silicone sleeve is located (anal)
- 4. Underneath the sleeve there is a space in which to insert the vibrating bullet with the battery
- 5. Press the button on the vibrating bullet to switch on the vibration
- 6. Place the silicone sleeve back into the plastic case

Maintenance instructions:

Before and after each use, wash the masturbator and use an erotic toy cleaner. Carefully pull the sleeve of the masturbator out of the plastic case. Remove the vibrating bullet from the sleeve. Wash the sleeve and rinse the inner tunnel under running lukewarm water. Then apply the cleaner, wait 5 minutes and rinse it again. After drying it completely and thoroughly, powder it with masturbator powder. Try to powder it inside as well and spread the powder with your fingers. Put the bullet back into the pouch and slide the sleeve back into the plastic case. To fix the position, you can twitch your hand downwards forcefully and use gravity and centrifugal force to settle the sleeve into the sleeve.

Lubrication:

Realistic materials can only be used with water-based lubricants. Usage of silicone-based lubricants may damage the surface of the material! These type of damage cannot be claimed.

Water resistance:

The masturbator is splash-proof. Due to the electronics inside the masturbator, try to expose it to direct running water as little as possible. Never submerge the masturbator in water or wash it when connected to the vibrating bullet.

Power supply:

3x LR44 battery

Material:

TPE material