



HOW TO CARE

- Wash toy after each use with liquid anti-bacterial soap and water.
- Pat dry with soft, cotton towel and allow to air dry completely.
- For maximum pleasure, use lubricant with this product.

HOW TO USE

Press the **U** button on plug to put into standby mode.

You may now use either the remote or the plug to change functions.

- Press the *w* button on the remote to cycle through functions or press and hold the *b* button to put back into standby mode.
- Press the U button again to cycle through functions on the plug.

Press the button to turn on the Warming Function – For maximum heat, let warm up for 5 minutes before use.

To turn off the plug completely, press and hold the **U** button on the plug for 3 seconds.

To turn off the Warming Function, press and hold the button on the plug for 3 seconds.

NOTE: Renegade Sphinx remote has a built-in non changeable non rechargeable battery.



For warranty information, latest products, and news visit us at:

www.nsnovelties.com