



Solstice, an App-controlled smart vibrator, bring you a pleasant experience.



^{*}Size description: Maximum diameter of the body: 33mm, Maximum length of the body: 99mm Bottom length/width: 89/28mm, Total length of the product: 132mm

Specification:

Product name: Solstice | Model: SMV03 | Size: \$\phi33x99(132)mm | Materials: Body-safe silicon/ABS Weight: 92g | Color: Black/Red | Charging Time: about 90 minutes | Operating Time: about 120 minutes Battery: 220mAh Li-Ion Polymer | Charging Voltage: 5V | Max. Charging Current: 300mA

Product package:

Solstice x1 User Manual x1 Charge Cable x1 Pouch x1

^{*} Multi-function key definition: Short press power on, Short press to switch pattern mode after device power, 3 seconds long press power off.

Use Steps:

Step 1: App Download

- 1. Search for "Whats Sense" in iOS App Store or Google Play.
- 2. Scan below QR code to download the App.





Whats Sense

Step 2: Turn on & Turn off



Press the multi-function button to turn on the device. Long press the multi-function button for 3 seconds to turn off the device.

Tips: Solstice will turn off automatically when it disconnected with App in 15 minutes.

Step 3: Run Whats Sense App.



Independent Modes(Without Smartphone)





Charging:

Plug DC Port of USB-DC cable to charging port, the LED light will be on when charging; and the LED light will be off when charging finished.



Tip: please run out of battery capacity in the first-time usage, and charging about 90 minutes continuously

Before Usage

Please clean device with cleanser or warm water and anti-bacterial soap before first use.

After Usage

Please clean device with cleanser or warm water and anti-bacterial soap and dry it.

Storage

Keep device in a cool and ventilated place. Avoid direct sunlight and keep it away from children.

Notice

This product is only suitable for adults over the age of 18, please keep away from children, please stop using if you feel unwell during use.

Fault Diagnosis

I.In offline mode, turn on the product. If you press the multi-function button again and fail to enter the vibration mode, please check if you need to charge.
In the phone control mode, open the magic motion product, if you are unable to establish a connection with the app, please check the phone and power.

Risk of injury

Remove piercings or jewelry in the genital area before use. Do not use the toy on irritated or damaged skin. Stop using the toy if you experience pain or feel unwell during use. Do not use the toy if it is in unusually hot or damaged or deformed.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance and void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 35 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates use and can notate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to madic communications. However, there is no guarantee that interference wit not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Regrient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- ~ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that