

PRETTY LOVE SHELL VIBRATOR



User manual

CONTROL

- 1) Turn on the vibrator by briefly pressing the "power" button on the bottom of the vibrator. The LED will light up and the vibrator will switch to standby mode.
- 2) Briefly press the button with the "wave" symbol to switch between the individual vibration programs.
- 3) For use with the remote control, press the "power" button on the remote control to turn it on.
- 4) Briefly press the button with the "wave" symbol on the remote control to switch between the individual vibration programs.
- 5) Briefly press one of the two "power" buttons to switch the device to standby mode.
- 6) Briefly press both of these buttons if you want the Shell to be completely turned off..

MAINTENANCE

After each use, rinse the product with lukewarm water.

We also recommend using an [erotic cleaner](#), which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The product is **not waterproof or water resistant!**

LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The product is powered by a AAA battery. For longer battery life, we recommend using alkaline or rechargeable batteries.

The remote control is powered by two AAA batteries.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find a vibrator and a remote control.