

设计受控图稿

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

⚠️ DANGER

As with most electrical appliances, electrical parts are electrically live even when the switch is off. To reduce the risk of death by electric shock:

- Always unplug the appliance immediately after use.
- Do not use while bathing.
- Do not place or store the appliance where it can fall or be pulled into a tub or sink.
- Do not place or drop the appliance into water or other liquid.
- If the appliance falls into water, unplug it immediately. Do not reach into the water.

⚠️ WARNING

The appliance, filter, and attachments contain magnets:

This appliance and some official accessories contain magnetic elements that should be kept away from devices and objects that could be affected or damaged by magnetic fields. This includes pacemakers, defibrillators, cards with a magnetic stripe, and electronic storage media.

⚠️ WARNING

To reduce the risk of burns, electrocution, fire, or injury to persons:

- This appliance should never be left unattended when plugged in.
- Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
- Use this appliance only for its intended use as described in the User Manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water. Contact Customer Support at cssteam@laifentech.com for examination and repair.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.

- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- Do not direct hot air toward eyes or other heat-sensitive areas.
- Attachments may be hot during use. Allow them to cool before handling.
- While using the appliance, keep your hair away from the air inlets.
- Do not operate with a voltage converter.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.
- For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.

READ AND SAVE THESE INSTRUCTIONS SERVICING OF DOUBLE-INSULATED APPLIANCES

- In a double-insulated appliance, two systems of insulation are provided instead of grounding.
- No grounding means is provided on a double-insulated appliance, nor should a means for grounding be added to the appliance. Servicing a double-insulated appliance requires extreme care and knowledge of the system, and should be done only by qualified service personnel.
- Replacement parts for a double-insulated appliance must be identical to the parts they replace.
- A double-insulated appliance is marked with the words "DOUBLE INSULATION" or "DOUBLE INSULATED". The symbol (square within a square) may also be marked on the appliance.
- WARNING: Do not use this appliance near bathtubs, showers, basins, or other vessels containing water.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

ALCI Safety (U.S. and Canada Only)

- This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature, and do not change the plug in any way.
- This appliance is equipped with a protective device (ALCI - Appliance Leakage Circuit Interrupter) that may make it inoperable under some abnormal conditions (such as immersion of the appliance). If the appliance becomes inoperable, contact Customer Support at cssteam@laifentech.com for examination and repair.
- The appliance has a reset and test button built into the plug, which should be operated each time the appliance is plugged in and used.
- To test, press the test button. The reset button will pop out, indicating that the appliance is safe to use. To reset, unplug the appliance and press the reset button. Plug in again to use your appliance.
- Note: If the ALCI trips while in use, the appliance should be unplugged. Press the reset button and reinsert the plug into the outlet. If the ALCI immediately trips for a second time, unplug the appliance and contact Customer Support at cssteam@laifentech.com.

Appliance Maintenance

- Regularly remove deposits from the air inlet using a dry towel, cotton swab, or toothbrush. When cleaning the air inlet, ensure that the power is turned off and the power cord is unplugged.
- Avoid pressing or rubbing the air inlet and outlet with your fingernails or sharp objects to prevent damage to the appliance.
- Do not use alcohol, nail polish remover, or detergents to clean this appliance, as they may cause malfunctions, cracks, or fading.
- Do not attempt to repair, disassemble, or modify the appliance yourself. If a repair is required, consult the User Manual or contact Customer Support at cssteam@laifentech.com.
- If any part of the appliance shows signs of malfunctioning or damage, immediately discontinue use and consult the User Manual or contact Customer Support at cssteam@laifentech.com.
- If the cord of the appliance is twisted, untwist it before use.

Product Features

High-Speed Brushless Motor

Laifen's independently developed 100,000 RPM high-speed brushless motor can generate powerful airflow to quickly dry hair.

Smart Temperature Control

This appliance has a built-in temperature control system that precisely regulates the air temperature to prevent overheating and hair damage. This prevents concentrated heat and protects hair from heat damage.

Negative Ion Generator

The built-in negative ion generator produces negative ions that neutralize the positive charges in the hair, reducing static buildup and preventing hair from becoming frizzy.

Noise Reduction Design

Through motor optimizations, high-frequency noises are modulated to frequencies imperceptible to the human ear. Additional noise reduction techniques, such as dynamic motor balance processing and sound-absorbing materials, further reduce noise, resulting in an even better user experience.



Function Descriptions



Power and Airspeed Settings

Toggle up or down to switch between airspeed settings.



* Before connecting to the power, ensure that the airspeed switch is in the off position.



Temperature Settings

Press to cycle between:



* Press 2 times to activate: * Long press to activate:



For more information on product usage please visit the official Laifen website: www.laifentech.com

Manufacturer: Shenzhen Shuyue Technology Co., Ltd.
Address: Room 1301, Building T7, Qianwan 1st Road No.399, Qianhai Kerry Business Center, Nanshan, Shenzhen, Guangdong, China

* Child Mode uses gentler temperatures suitable for drying children's hair. Toggle the airspeed switch to change between a low-speed 38°C airflow and a high-speed 48°C airflow.

Activating Temperature Cycling Mode:

When the appliance is in use, long press the temperature button for 1 second.

Activating Child Mode:

When the appliance is in use, press the temperature button 2 times.

Deactivating Modes:

Press the temperature button once or turn off the appliance.

* The illustrations of products, accessories, user interfaces, etc., in the User Manual are for reference purposes only. Due to product updates and upgrades, there may be slight differences between the actual product and the illustrations. Please refer to the actual product for accuracy.

Nozzle Usage



Gently place the nozzle on the head of the appliance. When you hear a "click" sound, it indicates that the nozzle has been securely attached.




Direct the appliance at a specific section of your hair and adjust the nozzle's position to achieve your desired drying or styling.


Attaching a magnetic nozzle to the appliance adjusts the airflow for more precise drying and styling. It can also be rotated to conveniently reach specific hair sections.

* Magnetic nozzles are accessories that come with certain Laifen hair dryer products. If the one that you want did not come with your product, it can be purchased separately.

* This appliance is compatible with the following official Laifen nozzles:



Concentrator Nozzle
Focuses the airflow for more targeted drying and styling.



Smooth Nozzle
Concentrates a gentle airflow for smoothing and reducing frizz.



Diffuser Nozzle
Spreads the airflow over a wider area. Perfect for curly hair.

Drying Instructions



Put your hair dry with a towel to remove excess moisture.



Maintain an appropriate distance between the appliance and your hair.



Start drying from the roots and gradually move towards the ends of the hair to ensure even heating and airflow distribution.



You can use your hands or a comb to assist in drying or styling your hair.

Cleaning and Maintenance



Before cleaning the filter, please ensure that the appliance is off and the power cord has been unplugged.
* The filter needs regular cleaning and maintenance to prevent blockage and ensure smooth airflow.



The intake filter is attached using magnets. Grasp the handle and pull the intake filter down to remove it from the handle.



Use a dry lint-free cloth, soft brush, toothbrush, or similar tool to remove any residue from the intake filter and the surface of the stainless steel filter.
* Do not use water to clean the stainless steel filter, as it may cause malfunctions.



After cleaning, align the intake filter with the handle slot and insert it. When you hear a "click" sound, it indicates that the magnet has been securely attached, and the installation is complete.

Common Faults and Troubleshooting

Malfunction	Possible Cause	Solution
Appliance doesn't turn on, blinking blue light	Power not properly connected	1. Check if the power is properly connected. 2. Check the circuit breaker, ensure the reset button is in the normal pressed state. 3. If the issue persists, contact support (see below).
Motor doesn't start, blinking yellow light	Overheating protection activated	1. Power off, shut down, and wait 5-10 minutes before restarting. 2. If the issue still cannot be resolved, contact support (see below).
Motor doesn't start, blinking red light	Protection mode activated due to external component issues	1. Power off, shut down, and wait 5-10 minutes before restarting. 2. If the issue still cannot be resolved, contact support (see below).
Motor doesn't start, blinking red light	Inlet or outlet blocked	1. Please clean the intake filter and exhaust vent, ensuring there are no blockages, then restart. 2. If the issue still cannot be resolved, contact support (see below).
5-Color LED ring not working, but the motor starts normally	Faulty 5-Color LED-ring circuit board	Contact support for assistance (see below).
Sparks, tremors, but temperature and temperature control be changed	Controls are damaged	Contact support for assistance (see below).
Heating element turns red	Main control board malfunction or inlet/outlet blockage	1. Please clean the intake filter and exhaust vent, ensuring there are no blockages, then restart. 2. If the issue still cannot be resolved, contact support (see below).
Power cord or plug overheating	Damaged power cord or loose plug	1. By using a different outlet, ensuring the plug is correctly connected. 2. If any abnormalities are found, please contact support (see below).
Burnt smell during use	Internal components damaged	Contact support for assistance (see below).
Insufficient heat in hot or mode	Inlet blocked	1. Please clean the intake filter and exhaust vent, ensuring there are no blockages, then restart. 2. If the issue still cannot be resolved, contact support (see below).

Laifen Customer Support: cssteam@laifentech.com

Return Policy

30-Day Return Service

Laifen offers a 30-day return service. Within 30 days from the date of purchase, you can contact one of our Customer Service representatives by email at cssteam@laifentech.com to begin the return process.

To be eligible for a refund, you must:

- Return the appliance with all included accessories and gifts.
- Return them in their original packaging.
- Provide a valid proof of purchase.
- Ensure the appliance and accessories are resalable.

Return shipping costs:

- Returns caused by appliance quality issues will have shipping costs covered by Laifen.
- Returns for any reason other than appliance quality are the responsibility of the customer and all costs associated with returning the appliance, including shipping costs, will be funded by the customer.

Warranty & Support

Laifen 2-year limited guarantee*

Laifen offers a 2-year limited warranty on the hair dryers. Within two years from the date of purchase, if your appliance fails to function properly due to material or workmanship defects, we will provide repair or replacement services. Please note that depending on the availability of stock, the replacement may come in a different color or be an equivalent model. Warranty is only valid in the country or region of purchase.

What is not covered under warranty:

- Purchases from unauthorized resellers.
- Appliances with an expired warranty.
- Appliances without a valid proof of purchase.
- Appliances that have been modified, altered or repaired through unofficial channels.
- Appliances that were used for any purpose other than drying hair.
- Appliances used for professional or commercial purposes or exceeding "normal household operation" (more than two hours per day).
- Damage caused by operations that are not in accordance with the User Manual.
- Damage caused by any misuse or accident.
- Damage caused by excessive usage that is not normal wear and tear.

Get Professional Assistance from Laifen

If you have any further inquiries regarding our warranty policy or product usage, please feel free to contact us via email at cssteam@laifentech.com. We greatly appreciate your feedback and look forward to assisting you.

Laifen SE 2 High-Speed Hair Dryer

User Manual

laifen

图纸名称

SE 2-海外-吹风机-英语说明书

品名

吹风机

设计

徐春梅

制图日期

25.2.24

版次

第A0版

材质及工艺

80upm, 正反印七折页

尺寸

133mm*133mm

备注

料号

修订记录 (日期)