

WARRANTY INFORMATION

Picobong™ warrants this toy for a period of ONE (1) YEAR, after the date of original purchase, against defects due to faulty workmanship or materials. If you discover a defect and notify Picobong™ during the warranty period, Picobong™ will, at its discretion, replace the toy free of charge.

The warranty covers working parts that affect the function of the toy. It does NOT cover cosmetic deterioration caused by fair wear and tear or damage caused by accident, misuse or neglect. Any attempt to open or take apart the toy (or its accessories) will void the warranty.

Claims under warranty must be supported by reasonable evidence that the date of the claim is within the warranty period. To validate your warranty, please keep a copy of your original purchase receipt together with these warranty conditions for the duration of the warranty period.

To claim your warranty, fill in your details under the CONTACT US section of PicoBong.com. A Picobong™ team member will get back in touch with you with further instructions on where to return your item. You will be emailed a Return Merchandise Authorization (RMA) number which should be returned with the Picobong™ product to your nearest Picobong™ office. These shipping costs are non-refundable, but replacement items will be shipped back to you carriage paid. This undertaking is in addition to the consumer's statutory rights and does not affect those rights in any way.

USING YOUR PICOBONG™

Hold down + button to activate your Picobong™ toy. Continue pressing + button to increase vibration intensity and – button to decrease.

2-BUTTON CONTROLS

While activated and at a maximum intensity, hold + button for two seconds to switch to next vibration pattern. Continue this process of pressing + button for two seconds to cycle between different modes. Return to continuous vibration by pressing – button.

Press – button to decrease vibration intensity. Hold – button to turn off your toy.

3-BUTTON CONTROLS

To turn on, press and hold the + button.

Press the center button of the interface to move through the different vibration patterns.

Press the – button to decrease vibration intensity and the + button to increase vibration intensity.

To turn off, press and hold the – button until vibrations stop.

WARNING: If vibrations stop for any reason during use, stop and remove massager and check cap is securely fastened. There is a safety measure that will prompt you in case the cap has become loose due to vigorous use. See www.Picobong.com for further technical specs, troubleshooting advice and information on your warranty.

CLEANING, STORAGE AND SAFETY

Use only water-based lubricants with your Picobong™ toy. Silicone-based lubricants will damage the silicone on the outer shell of your toy.

Never use massage oil or hand cream as lubricants with your toy.

Clean your toy with the Picobong™ Toy Cleanser or warm water and anti-bacterial soap.

After washing, rinse and pat dry with a lint-free cloth.

Avoid cleaning solutions containing alcohol, petrol, or acetone.

All PicoBong products are waterproof. Keep toy tightly closed during cleaning.

Avoid leaving your Picobong™ toy in direct sunlight, and NEVER expose it to extreme heat.

Do not use on swollen or damaged skin. Keep your Picobong™ toy out of the reach of children.

If your Picobong™ toy appears to function abnormally, turn off and consult the CUSTOMER CARE section on PicoBong.com where you will find a number of troubleshooting tips. If you experience any other problems with your Picobong™ product, please contact: CUSTOMERCARE@PICOBONG.COM.

Disclaimer: Users of this product do so at their own risk. Picobong™ and its retailers will not assume any responsibility or liability for the use of this toy. Further, Picobong™ reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revisions or changes.

IMPORTANT: For Adult Use Only. Those who may be pregnant, have a pacemaker, diabetes, phlebitis or thrombosis should consult with a medical professional regarding the risk of blood clots before using any personal massage product.