EN INSTRUCTION MANUAL

Please read carefully all the instructions contained in this booklet as they provide important advices about safety, use and maintenance.
This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.
Cleaning and user maintenance shall not be made by children without supervision.
If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

FEATURES

- Tourmaline ceramic hair straightening plates, size 25 mm x 120 mm
- Digital Display
- Adjustable thermostat: from a minimum of 130°C to a maximum of 230°C.
- Resistenza in ceramica MCH: permette di raggiungere la massima temperatura in 10 secondi
- Check system: the temperature control and monitoring device makes it possible to maintain and ensure the temperature set on the display at all times while working, ensuring maximum performance by the straighteners.
- Auto Shut-off: the straighteners switch off automatically after 60 minutes of inactivity.

SAFETY ADVICES

Danger: do not leave the packaging (plastic bags, cardboard boxes, staples) within the reach of children, as it is a potential source of danger.
Please check the power supply of the electric socket before using the product. Make sure the voltage of the electric socket is the same as that of the appliance.
Caution: The metal plates are very hot, and any contact with them causes burns.
In the event of the product being dropped, check that there is no visible damage before any further use. Since it is a professional appliance, if it has been damaged, please contact only an authorised service centre to have it repaired.
To avoid dangerous overheating, do not keep the appliance switched on unnecessarily when not in use.
Never immerse the appliance in water. Risk of electric shock.
NEVER touch the appliance with wet or damp hands and/or feet. Do not use extension cables.
Do not use in public bathrooms or showers.
After use, disconnect the appliance from the socket by pulling the plug and not the power cable.
Do not leave the appliance exposed to the weather (rain, sun, etc..).
Warning - Danger: do not put the appliance close to your face or eyes, there is a danger this could result in burns.
Always keep the plates clean from dust, dirt, hair sprays and gels.
After use, always unplug the appliance and wait until the plates have completely cooled before storing it.

INSTRUCTIONS

1. A. Insert the plug into the socket.
2. Turn the appliance on using the ⏻ switch.
3. Set the temperature using the + and - buttons.

For perfect straightening, take a small lock of hair and insert it between the plates of the appliance, holding it at a right-angle. Slide the straighteners from the hairline along the full length of the hair. Repeat the process until finished. Avoid contact between the metal parts and your skin: danger of scalding or burns. Be careful not to place the straighteners on surfaces that could catch alight: danger of fire.

PACKING AND MAINTENANCE

After removing the packaging, check the integrity of the appliance. In particular, that the appliance is intact and has no visible damage that could have been caused in transport. If in doubt, do not use the appliance, and contact only an authorized service centre. This appliance must only be used for the purpose for which it was specifically designed, i.e. as a hair straightener. Any other use should be considered inappropriate and therefore hazardous. The manufacturer cannot be held liable for any damage resulting from improper or incorrect use. To avoid dangerous overheating, do not wrap the power cord around the appliance. Before using the appliance, ensure that it works perfectly, any defects may cause damage. In this case the manufacturer can not be held liable. Before performing any cleaning or maintenance work, unplug the appliance and wait until it is at room temperature. Always keep the appliance clean. In the event of faults and/or malfunctions, please only contact your authorized service centre.

WARRANTY

Warranty Clauses

- The device is guaranteed 12 months for professional use (or purposes related to business or trade), or in case of second-hand goods, from the date of purchase against material and manufacturing defects as per Legislative Decree nr 24 of February the 2nd 2000.
- Warranty does not cover extenal and aesthetic parts, handles, spare parts, and all damages owing to improper uses of the device, wrong installation or different use than those wrote on instructions, thus factors out of normal utilizations.
- Warranty lapses if the device has been opened, either tampered, or repaired by not authorized staff.
- The device must be repaired by an authorized technical assistance centre. Charges and transport risks will be supported by the final client.
- Device sales are reserved to professional use only
- Warranty validity depends to the reception of Warranty Certification that must be stamped by the retailer. If case of direct delivery to authorized technical assistance centre, Warranty Certification must be attached.
- Final client either contract holder must inform the seller of the lack of conformity within a period of two months from the date on which he detected such lack of conformity. The communication must be sent by post through letter with advice of delivery or certified e-mail to LABOR PRO SRL or to authorized vendor.

ATTENTION! THE WARRANTY SHALL BE CONSIDERED VALID ONLY IF THE PURCHASING DOCUMENT HAS BEEN PRESERVED.

The warranty responds only to the following law requirements: Italian Legislative Decree nr 24 of February the 2nd 2000 that refers to European Directive 1999/44/EC and paragraph 1-bis, section II item I title III book IV of Civil Code. The consumer is the holder of the rights foreseen by the the law and those rights are not affected by the guarantee.

Leggere attentamente le avvertenze contenute nel seguente libretto in quanto forniscono importanti indicazioni riguardanti la sicurezza, l'uso e la manutenzione.

Read the notes in the following booklet carefully as they provide important information regarding safety, use and maintenance.

Lea cuidadosamente las instrucciones contenidas en este folleto, ya que proporcionan información importante acerca de la seguridad, el uso y el mantenimiento.

Leia atentamente as instruções contidas nesta brochura pois fornecem informações importantes sobre segurança, utilização e manutenção.

Lisez attentivement les avertissements contenus dans le suivant livret parce qu'ils fournissent des renseignements importants pour la sécurité, l'utilisation et l'entretien.

Citiți cu atenție instrucțiunile din această broșură, deoarece acestea oferă informații importante cu privire la siguranță, utilizare și întreținere.

DATI TECNICI/TECHNICAL FEATURES/ RENSEIGNEMENTS TECHNIQUES/ DATOS TÉCNICOS/DADOS TÉCNICOS/DATE TEHNICE:

Art.: B341EVO
Item: RM-30
220-240V - 50/60Hz- 40W
Made in P.R.C.

RoHS

Questo apparecchio è contrassegnato dal simbolo della raccolta differenziata relativa allo smaltimento di materiale elettrico ed elettronico. Ciò significa che questo prodotto deve essere portato presso un centro di raccolta differenziata conformemente alla direttiva europea 2002/96/CEE, in modo tale da potere essere riciclato o smantellato così da ridurne l'eventuale impatto ambientale. Per ulteriori informazioni in proposito si consiglia di rivolgersi alla propria amministrazione locale o regionale. I prodotti elettronici che non sono oggetto di una raccolta differenziata sono potenzialmente nocivi per l'ambiente e la salute umana a causa della presenza di sostanze pericolose.

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human healt from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection system or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Este aparato está marcado con el símbolo de recogida selectiva relativa a la eliminación de material eléctrico y electrónico. Esto significa que este producto se debe llevar a un centro de recogida selectiva de acuerdo con la directiva europea 2002/96/CEE, para que pueda ser reciclado o eliminado de forma que se reduzca el posible impacto ambiental. Si desea obtener más información sobre este tema, póngase en contacto con la administración local o regional. Los productos electrónicos que no son objeto de una recogida selectiva son potencialmente dañinos para el medio ambiente y la salud humana como consecuencia de la presencia de sustancias peligrosas.

Este aparelho está marcado com o símbolo de recolha diferenciada relativa à eliminação de resíduos de material elétrico e eletrónico. Isso significa que este produto deve ser levado a um centro de recolha diferenciada de acordo com a Diretiva europeia 2002/96/CE, de forma a poder ser reciclado ou desmantelado de forma a reduzir o impacto ambiental. Para mais informações a este respeito, aconselha-se consultar a administração local ou regional. Os produtos eletrónicos que não são alvo de recolha diferenciada são potencialmente nocivos para o ambiente e a saúde humana, devido à presença de substâncias perigosas.

Cette marque indique que, au sein de l'UE, ce produit ne doit pas être éliminé avec les autres produits ménagers. Pour prévenir les dommages éventuels sur l'environnement ou la santé humaine causés par une élimination non-contrôlée des déchets, recyclez-le de manière responsable pour promouvoir la réutilisation durable des ressources matérielles. Pour rendre votre appareil usagé, veuillez utilser le système de collecte et de récupération ou contactez le détaillant où le produit a été acheté. Ils peuvent emmencer ce produit dans un lieu ou il sera recyclé de manière à protéger l'environment.

Acest aparat este marcat cu simbolul de reciclare privind eliminarea materialelor electrice și electronice. Acest lucru înseamnă că acest produs ar trebui să fie adus la un punct de colectare, în conformitate cu Directiva Europeană 2002/96 / CEE, astfel încât să poată fi reciclat sau dezasamblat, în scopul de a reduce posibilul impact asupra mediului. Pentru mai multe informații despre acest lucru vă rugăm să contactați administrația locală sau regională. Produsele electronice care nu fac obiectul unei colectări separate sunt potențial dăunătoare mediului și sănătății umane ca urmare a prezenței unor substanțe periculoase.

Imported and distributed by: Labor Pro s.r.l. - Via Giuntini 34/A, 50053 Empoli (FI) ITALY
www.laborprosrl.com

PLUMLONG

PIASTRA IN TOURMALINE - Manuale d'istruzioni

TOURMALINE HAIR STRAIGHTENER - Instruction Manual

PLANCHA EN TURMALINA - Manual de Instrucciones

PLACA EM TURMALINA - Manual de instruções

LISSEUR EN TOURMALINE - Manuel d'instructions

PLACĂ DE TURMALINĂ - Manual de instrucțiuni

LABOR pro

Bellezza per Passione