

BLUSH M FOR MEN SPINMASTER PRO MASTURBATOR



User manual

CONTROL

- 1) The front panel offers a total of 4 buttons. Hold down the bottom power button for approximately 2 seconds to turn the device on and off.
- 2) The confirmation of the masturbator operation will be a light indicator with the number 0.
- 3) Short presses of the button marked "rotating wheel" then select between the different programs rotation, approximately 2 seconds hold to switch it off.
- 4) The button with the "star symbol" will automatically offer the Turbo Climax Boost function. This function is under program number 8.
- 5) The next control is the button with the " wheel with vibration line " symbol, which you press briefly to select the individual vibration programs, approximately 2 seconds hold to switch it off again.

MAINTENANCE

After each use, rinse the masturbator sleeve with lukewarm water.

We also recommend using an [erotic cleaner](#), which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

ATTENTION! To remove the inner sleeve, after removing the protective cap, turn the entrance at the top counterclockwise, it will immediately release and can be conveniently pulled out.

Then carefully unzip the translucent centre section and remove the inner transparent textured sleeve.

WATERPROOF

The product is **not water resistant or waterproof!** Only the masturbator sleeve is waterproof.

LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The product is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find a masturbator and USB cable for charging.