



Quick Start Guide

pmd | clean pro

SMART FACIAL CLEANSING DEVICE

CAUTION: Please read this manual carefully before using

GETTING STARTED:

Cleansing:

Mode 1: Gentle Vibration
Mode 2: Intense Vibration

Massaging:

Mode 1: Gentle Pulsation
Mode 2: Intense Pulsation

HOW-TO USE

Cleansing:

Instructions: Rinse face with warm water and gently rub in cleanser. Rinse PMD Clean Pro under water and power on device, we recommend modes 1 and 2 for optimum cleansing results. Move brush head in circular motions, cleansing entire face, it is safe to spend more time in areas that may be of personal concern. Cleanse once or twice per day.

Massaging:

Instructions: Apply skincare products and use back side of the PMD Clean Pro on mode 3 or 4 to gently massage, by powering on ActiveWarmth™ on the PMD Clean Pro, serums will be more effective and absorb deeper into the skin. We recommend using mode 3 or 4 for massaging. By operating at a perfect frequency, the PMD Clean Pro lifts, firms and tones the skin, through the pulsations of the device, blood flow is stimulated and collagen production is increased

Charging:


Charge device for 2-3 hours before first use.

Care Instructions:

Wash with soap and warm water, pat dry with a clean towel, and let it air dry.

INCLUDES:

PMD Clean Pro
Charging Cord
Storage Case



The PMD Clean Pro comes with a One-Year Limited Manufacturer Warranty.

FAQ's

Does the brush head need to be replaced?

No, our silicone brush is odor-resistant, antibacterial, hypoallergenic, and waterproof. The brush head is hassle-free and never needs replacing.

How long should I use the massager?

We suggest using the massager for one minute per area daily.

How long does the PMD Clean Pro battery last?

150-180 minutes.

Can I use this in the shower?

Absolutely! The PMD Clean Pro is waterproof and safe to use anywhere.

Can I use my own soap?

Yes! The PMD Clean Pro works with all liquid cleansers.

Caution and Warnings:

Use only as directed. Not following instructions may lead to rash, redness, itching or even injury. If this occurs, discontinue use and consult a medical professional. Product is intended for external use only. Avoid sensitive areas, including any area with broken, irritated, or itching skin. Keep product out of reach of children. PMD is not responsible for malfunction or injury if the product is not used as intended. Not intended for clinical or commercial use. The effects of the PMD Clean are not always immediately visible and results may vary. If you have any questions regarding application, please reach out to our experts at 888-445-4532.

#BRILLIANTCONFIDENCE

To learn more visit: eu.pmdbeauty.com/clean-pro

FOLLOW US

Youtube
@pmd

Instagram
@pmdbeauty

Pinterest
@pmdbeauty