

# PLAYBOY SPINNIG TAIL TEASER ANAL PLUG

## User manual



### CONTROL

- 1) The power button is used to turn the pin on and off by holding it for approximately 2 seconds. The aid is put into standby mode.
- 2) Short presses are then used to select the individual rotation rhythms.
- 3) The second button with the wave symbol is used to control the individual vibration and pulsation modes by short presses.
- 4) Long press and hold this button to switch off the vibrations.
- 5) To be able to operate with the remote control, the pin must be in standby mode.
- 6) Next, you must remove the safety insert in the remote where the battery is located.
- 7) You can then operate the pin both manually and with the remote control.

### MAINTENANCE

After each use, rinse the product with lukewarm water.

We also recommend using an [erotic cleaner](#), which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

### WATERPROOF

The product is fully **waterproof**, so maintenance is very easy.

It may get splashed with water, but you can safely immerse it in water and enjoy water play.

### LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

### DRIVE AND CHARGING

The product is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently.

The remote control is powered by CR2032 battery.

### STORAGE

Store separately from other erotic aids in a dry and dark place.

### PACKAGING CONTENTS

In the package you will find a anal plug, remote control, magnetic USB cable for charging and CR2032 battery.