


## USER MANUAL

eggo - wireless silicone face cleansing device

### Read before using.

#### Product specification

Size: 88,5x116x89 mm  
Low speed: 4900 pulses/minute  
Low-middle speed: 6100 pulses/minute  
Middle speed: 7100 pulses/minute  
Middle-high speed: 8000 pulses/minute  
High speed: 8500 pulses/minute  
Battery capacity: 420 mAh  
Voltage: 3,9 V  
Power: <0,45 W  
Voltage: 20-100 mAh  
Net weight: 120 g  
Charging time: 2 hours  
Operating time: up to 5 hours  
Automatic turn-off after 3 minutes




\*Default speed is set to normal (middle).

#### How-to use?

1. Remove your makeup, then damp your face and eggo.
2. Apply face cleansing gel or foam to your face.
3. Turn on the device and choose your preferred speed.  
With circular motion massage your face.
4. Adapt the speed to your choice.
5. After you finish, rinse your face and eggo with water.  
Make sure you dry your device with a cloth or a towel.
6. Put on all the regular skincare products that you normally use after your daily cleansing routine.

#### Technical details



#### Warnings

**1. The device doesn't have to be charged for the first use as you will receive it pre-charged. If the battery of the device is full, you will not be able to charge it, so you first have to make sure the battery is low and then charge it.**

**\*If the charging indicator turns off after a few minutes of charging, it means that the battery of the device is full.**

1. Keep the device and the charging stand dry before charging. Store the device in a dry place so that water does not penetrate deeper and damage the device.
2. Silicone is suitable for use on sensitive and acne-prone skin. The product can also be used by pregnant women.
3. The product is suitable for use on the face and body, but not on the eyes.
4. Silicone is waterproof, but the device is not intended for soaking in water. After each use, rinse the device under water and dry it.
5. Each time you press the on / off button and +/-, the light comes on once. When charging, the light will flash until the device is fully charged. When the battery is fully charged, the light turns off.
6. With one charge you can use the device for up to 5 hours or up to a maximum of 100 times.
7. Charge the device by placing it in the supplied stand and connect the stand to the supplied cable, located at the bottom of the packaging. If the light is off, the device does not charge. Move the device to establish contact with the stand and with the connectors on the bottom of the device.
8. The device is not suitable for children.

## Product characteristics

1. Skin and environment friendly device, made of soft, hypoallergenic silicone that doesn't irritate your skin.
2. 1608 bristles absorb impurities and remove makeup residue while deeply cleansing your face.
3. Small bristles on the back side of the product are specially appropriate for your t-zone and other oily parts of your face.
4. 5-speed frequency improves blood circulation, restores fatigue, restores freshness, smoothes smaller wrinkles and helps to make skin more elastic and healthy.
5. With the IPX6 water resistance level, you can wet the product with water, however, you should not soak it in it. You can use it in the shower, but make sure it is dry when you charge it.
6. The device turns off after 3 minutes, which is also the recommended time to use for a one-time cleaning.
7. The battery charges in 2 hours, and you can use the device up to 100 times.
8. The ergonomic shape is easy to use as it fits nicely in the palm of your hand. The device is therefore pleasant to hold and doesn't slip when wet.
9. The device charges in a stand in which you insert the supplied cable and connect it to the electricity.

**\* The charging cable is under the plastic cover of the product (at the bottom of the box).**

**The WARRANTY is valid for 1 year from the purchasing date of the product, upon submission of the original invoice. It is not possible to claim the guarantee without an invoice. Contact your device seller to enforce the warranty.**

**General wear and tear due to use is not taken into account in the warranty claim, but only the defect that occurs in itself.**