

for fun!

ENGLISH

User manual

Congratulations on the purchase of your TOYJOY product. TOYJOY's award winning erotic novelties provide an extra touch to your sex life. To enhance the fun with this product and to ensure proper and safe use, please read the following instructions carefully before use.

Safety instructions

- Always check your product carefully before use. Do not use the product if it has any defects like broken, sharp or scratched material.
- Do not use this product if you are allergic to any of the used materials, which you can find on the packaging.

 Do not use this product on irritated skin or recently injured areas.
- For extra comfort use a water-based lubricant. Oil- and silicon-based lubricants may damage the materials.
- If you are experiencing any discomfort or pain, stop using this product immediately.
- TOYJOY's products are designed to prevent it from being inserted too deeply. Always make sure a part of the product is always outside your body, as this allows you to remove the product. Cleaning instructions

- Clean your product before and after use
- Make sure the product is 100% dry before storing.
- Use warm water and mild soap or a toy cleaner to clean this product.

- Storage instructions

- Store this product in a dry, dust-free place at room temperature.
- Do not expose to direct sunlight.

- Keep your products separate from each other to avoid chemical reactions. For example, you could use a small box or a satin pouch.
- Instructions for rechargeable products Do not charge your product in or around water.

- Only use the provided USB charger cable, using a different cable might
- damage the product. Do not force the charging cable, or you might damage the connectors.
 - Make sure the plug aligns with the port, then connect it.
 - Plug your charging cable into a USB port.

- structions for battery operated products Only use the correct battery, which is mentioned on the packaging of your product.
 - Check the battery contacts and make sure they are clean and unobstructed.
 - When inserting the batteries, make sure to observe the polarity (+ and -) as instructed. When replacing the batteries, be sure to replace all batteries with new
 - ones. Remove your battery, if you will not be using your product for some
 - time, to prevent damage from battery leakage and corrosion.
 - Prevent short circuit in the battery compartment.

Environmental protection Please recycle your packaging materials in accordance of your local

- recycling guidelines The "crossed-out bin" symbol indicates that this product, and the
- batteries it contains, cannot be disposed with household waste. The symbol indicates separate collection for electrical and electronic equipment. arnings

- Keep this product and packaging out of the reach and sight of children. Sold as an adult novelty, not for medical use.
 - Do not share this product with others.
- Do not heat or cool the product, unless recommended to do so. Do not excessively or forcefully bend, stretch, or obstruct the
- mechanical movement of the product to avoid malfunction of the inside mechanics or external damages.
- If the product is not water- or splash proof, do not use it in or near water.
- For waterproof products, make sure the battery compartments are closed before using it in water. Splash proof products cannot be used in water but can be cleaned with
- water Keep the product and batteries away from fire
- The supplier cannot be held liable in any way for defect or damage caused by incorrect use.
- Gebruik het product niet in, of in de buurt van water als het product et water- of spatproef is.
- Voor waterbestendige producten geldt dat ervoor gezorgd moet worden dat de batterij compartimenten goed gesloten zijn voor
- gebruik in water. Spatwaterbestendige producten kunnen niet in het water gebruikt worden, maar wel worden schoongemaakt met water.
 - Houd het product en de batterijen weg van vuur. De leverancier kan niet aansprakelijk worden gesteld voor enige
 - defecten of beschadigingen door onjuist gebruik

aranti

De wettelijke garantie is van toepassing op dit product. TOYJOY garandeert binnen de garantietermijn en bij normaal gebruik dat het product vrij Is val materiaal- en fabricagefouten. Gebruiksslijtage is hiervan uitgesloten. De garantie start op de datum dat je het product hebt aangekocht. Je aankoop bon met bon nummer, productbeschrijving, originele datum van aankoop, prijs en de gegevens van de verkoper vormen een geldig aankoopbewijs.