

# VIBRATOR DREAM TOYS

## MIDNIGHT MAGIC

### DIONE REMOTE

## User manual



### CONTROL

- 1) Briefly press the on/off button to turn on the vibrator.
- 2) The circle button on the remote can be used to change the vibration settings and the vibration can be paused using the pause button.

### MAINTENANCE

After each use, rinse the vibrator with lukewarm water and soapy detergent.  
You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.  
Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

### WATERPROOF

The vibrator is **waterproof**, so maintenance is very easy.  
It may get splashed with water, but you can safely immerse it in water and enjoy water play.

### LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

### DRIVE AND CHARGING

The vibrator is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank.

The remote is also powered by an internal battery which is charged by the same cable as the vibrator.

### STORAGE

Store separately from other erotic aids in a dry and dark place.

### PACKAGING CONTENTS

In the package you will find a vibrator, remote control and USB cable for charging.