EASYTOYS VIBRATING EGG WITH REMOTE CONTROL BLACK

Instructions for use:

1) Press the on/off button for 2 seconds to put the egg in standby mode

2) The egg welcomes you by lighting up the LEDs

3) If you want to operate the egg with the remote control, you must always first switch on the device itself by long pressing the on/off button

4) Afterwards, the middle button on the controller is used to switch the egg on and off by pressing it with a short press

5) The + and - buttons are used to select the speed, the buttons with the wave symbol are used to select the degree of pulsation

Maintenance instructions:

Before and after each use, use the erotic cleaner. Device is water, so maintenance is very easy and it can also be cleaned with water.

Lubrication:

Use only water-based lubricants. Other lubricating gels could damage the surface of the erotic toy!

Water resistence level:

The egg is water resistant, meaning that water can splash on it. However, it must not be immersed in water!

The remote control is not water resistant.

Power supply:

Integrated Li-on battery in the egg and 1x CR2032 battery for the remote controller (inside the package)

Package contents:

Egg, remote controller, USB cable