

HUEMAN INFINITI IGNITE VIBRATING COCK RING



User manual

CONTROL

- 1) Turn the product on and off by pressing the "power" button for approximately 3 seconds. The product will start to standby mode, it will notify you by illuminating the LED.
- 2) Short presses of the same button to switch between vibration and pulsation modes.
- 3) To use the remote control, put the product in standby mode and press the "power" button on the remote for 3 seconds to start the vibration.
- 4) Short presses of the "+" button on the remote control change the vibration and pulsation modes and press the "-" button to go back one mode.
- 5) Long press the "power" button again to pause the vibration.

MAINTENANCE

After each use, rinse the product with lukewarm water.

We also recommend using an [erotic cleaner](#), which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The product is **water resistant**, so maintenance is very easy.

The product can be splashed with water, but you **MUST NOT immerse it in water!**

Waterproof means that you could completely submerge the product in water and enjoy water play.

Due only to the water resistance of the product, this is not possible in this case.

The remote control **is not waterproof or water resistant!**

LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The product is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently.

The remote control is powered by CR2032 battery.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find a vibrating ring, remote control, magnetic USB cable for charging and a CR2032 battery.