



DISCLAIMER

All rights reserved. This product is under no circumstances to be considered as a medical device.

Only use the product as instructed. Compatible with water-based lubricants. Read the user manual carefully before use.



SPECIFICATIONS

Product size:

Ø 31x45x72 mm
Ø 1.2x1.7x2.8 inches.

Materials:

Silicone, ABS.

Vibration modes:

10 modes.

Waterproof:

IPX7.

Max. noise level:

<55 dp.

Power:

Incl. USB charging cable.

Battery:

Polymer Lithium Battery, 70mAh, 5V.



USER MANUAL

Before use

Charge the toy completely before first use with the included USB cable.

Use

Place the ring around the base of the penis when the penis is flaccid. During an erection, the ring tightens around the penis and restricts the blood flow. This provides a harder and long-lasting erection and more intense orgasms.

How to operate

Keep the vibration button pressed down for 2 seconds until the light inside the ring starts to burn, the toy is now turned on. Briefly press the vibration button to start the vibrations and to switch to a different vibration mode. Turn off the toy completely by keeping the vibration button pressed down for 2 seconds.

Lubricant

Use a water-based lubricant. Other lubricants can negatively affect the material and are therefore discouraged.

Cleaning

Rinse the toy with lukewarm water. Apply toy cleaner and rinse it with lukewarm water again. Repeat this step if necessary. Lay the toy down to dry or dab it dry with a lint-free cloth or towel.

Storage

Safely store the toy in a dry and dark place, out of reach of children and animals. Use a toy bag to protect the toy from dust and scratches. Do not store the toy right next to other toys.

Safety instructions

A product that fits too tightly can cause circulatory problems and other injuries. Don't wear the product for more than 30 minutes. In case you feel pain and/or discomfort during use, you should stop using the product immediately and refrain from further use. Do not use the product if you have swollen or inflamed skin or other injuries to the penis. Do not use if you have allergic reactions to the material. Do not clean with products that contain alcohol, petrol, silicone, acetone, or any other corrosive substance. Do not use the toy in the neck

area. To avoid illness and infection, do not share the toy with others. Do not charge or use if the toy or charging cable is damaged. Do not use while charging, as this can cause an electric shock. To avoid an electric shock, do not allow the charging cable to encounter water. Do not use a USB hub to charge alongside other devices. To prevent fire, only use the charging cable with adapters that have short-circuit protection. In case of overheating, switch the toy off immediately and allow to cool before using again. Don't put the toy in a washing machine or dishwasher. Be careful if you use this toy with a condom because the condom can be damaged while using the toy. The toy is only to be used as intended and as directed. Only suitable for external application.

Disposal information

Do not dispose of the toy in household trash. Dispose of the toy in a collection point for the recycling of electronic devices. As a distributor of electronic equipment, we accept returns of discarded electrical and electronic equipment free of charge.

Need help?

If you have any questions regarding this product, do not hesitate to contact customer service.

E-mail: helpdesk@easytoys.com.
Telephone: +31 (0) 598-690 453.
For more information, please visit www.easytoys.com.