

HUEMAN GALAXY FORCE VIBRATING BUTT PLUG WITH REMOTE



User manual

CONTROL

- 1) To turn on and off, hold the "power" button for about 3 seconds. The LED will flash and the pin will enter standby mode.
- 2) Short presses of this button switch between the different vibration and pulsation rhythms.
- 3) For use with the remote control, place the product in standby mode and hold the "power" button on the remote control for approximately 3 seconds.
- 4) Short presses of the "+" button will turn on and change the vibration and pulsation modes.
- 5) Short presses of the "-" button return one level back.

MAINTENANCE

After each use, rinse the product with lukewarm water.

We also recommend using an [erotic cleaner](#), which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The product is fully **waterproof**, so maintenance is very easy.

It may get splashed with water, but you can safely immerse it in water and enjoy water play.

Remote controller is **not water resistant or waterproof!**

LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The product is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently.

The remote control is powered by CR2032 battery.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find a anal plug, remote control, magnetic USB cable for charging and CR2032 battery.