

GLAMOUR GLASS REMOTE VIBE BEADED PLUG

User manual



CONTROL

- 1) Holding the power button on the base for 2 seconds will turn on the LED under the button and put it into standby mode.
- 2) Short presses of the button turn on and change the individual vibration and pulsation rhythms.
- 3) Turn the pin off by holding the power button again for 2 seconds.
- 4) For use with the remote control, place the pin in standby mode.
- 5) Briefly press the bottom power button on the remote to turn on the vibration.
- 6) Change modes by briefly pressing the top button on the controller with the wave symbol.
- 7) Press the power button again briefly to pause the vibration.
- 8) To turn off the pin completely, you must use its own button.

MAINTENANCE

After each use, rinse the vibrator with lukewarm water and soapy detergent.

You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The vibrator is **waterproof**, so maintenance is very easy.

It may get splashed with water, but you can safely immerse it in water and enjoy water play.

LUBRICATION

Due to the material of the vibrator, you can use **lubricants of any base**.

DRIVE AND CHARGING

The vibrator is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. The remote is powered by a CR2032 battery.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find an anal plug, remote control, USB cable for charging and and CR2032 battery.