VUSH

SWISH

DUAL TIP CLITORAL VIBRATOR CARE AND INSTRUCTION MANUAL

HEY BABE, COME HERE OFTEN?

Welcome to your self love journey! Please welcome Swish to the stage! Who doesn't need an extra helping hand, and lucky for you, Swish has 2 to offer!

Swish is the dual tip clitoral vibrator that will truly change the game. The two tips perfectly hug the clitoris, acting like two fingers that know exactly what they're doing.

Swish comes with 10 levels to pick from and lucky for you, you can experience 2 levels at once with dual motors in the tips. Swish hugs your clitoris to give it all the best sensations and gets to all the spots you can't always see.

CHECK ME OUT



YOU'RE IN CHARGE

Before we can get down to the good stuff, your Swish will need to charge for 2 hours. Your charger will be in the lid of the toy tube.

Insert the main USB plug into any USB port. Connect the charger with the charge port on your Swish (those two fancy silver dots). You'll feel a slight pull and a click, followed by your Swish LED light flashing to let you know it's charging (just above the ♥!). Catch up on that show you've been meaning to watch - it won't be long! The LED will stop flashing when your Swish is ready to play.

For best performance, we recommend only charging your Swish with the provided VUSH charger.

TURN ME ON

Charge Swish for 2 hours to reach full charge. Hold down ♥ for a few seconds to turn on. Press ♥ to search through the 10 settings.

Make some magic!

Press and hold 🛛 to turn off.

PLEASURE TO MEET YOU

Settle in, get comfortable, and turn on your Swish. Choose your fave starting level. Swish is perfect for complete clitoral stimulation.

Two tips of Swish can be moved and controlled individually, meaning you can explore two modes at once. The dual tips allow for complete clitoral stimulation, even the bits you can't see. Position how you please and try different levels, patterns, and pressures to find how to best love yourself!

Lubrication:

If you'd like extra lubrication for your Swish, you can apply as much as you need to either tip. It's important to only use water-based lubricants like VUSH Feelin' Myself Intimate Gel with your Swish. Other oils, creams, or silicone-based lubricants can damage the high-grade silicone of your toy over time.

GOOD CLEAN FUN

Always clean your Swish thoroughly before and after each use. It's waterproof, so simply wash with clean water and unscented soap, then rinse and refresh with Clean Queen Intimate Accessory Spray for additional protection. Pop Swish back in its case once dry - ta da!

For those times when you need something quick and discreet (like when your roommate is using the bathroom for karaoke practice), you can also use a gentle wet wipe, like VUSH You Do You wipes.

Show your Swish a little more love and care! Always store Swish with its lid on, to avoid dust build up or damage from other materials, and to keep it safe from sunlight or other extreme heats.

SAFETY FIRST

Swish is for adult use only. Keep out of reach of children. Those who may be pregnant, have a pacemaker, diabetes, phlebitis, thrombosis, or any other condition, should consult with a medical professional regarding the risk of blood clots before using any personal massage product.

Do not use on areas that have pre-existing injuries or on swollen skin. For some, excessive use of vibrating devices can cause temporary numbness and loss of sensitivity. If this happens, take a break and treat yourself to another self love practice.

If pain occurs please cease use immediately. Consult a doctor before use if you have any implanted devices, such as a pacemaker, or if you have had any form of surgery on the relevant body parts. VUSH assumes no responsibility for misuse or excessive use of this product. Always switch off after use.

SPECS

PRODUCT SIZE:	POWER INPUT:
118 x 45mm	5V
MATERIAL:	BATTERY TYPE:
Medical grade silicone/ ABS Case	Flexible polymer lithium battery
PRODUCT WEIGHT:	FREQUENCY:
^{115g}	10 modes
WATERPROOF:	BATTERY CAPACITY:
IPX7	450mAh
CHARGE TIME:	WORKING CURRENT:
120 minutes	\$250MA
USE TIME:	MOTOR SPEED:
120 minutes	15000RPM ±10%
NOISE:	INTERFACE:
Less than 50db	Single button
LOW BATTERY WARNING	MAGNETIC CHARGING

DISPOSAL ADVICE

Dispose of according to your local regulations.

WARRANTY

We provide a 1 year customer warranty from when you first purchased your product. After 1 year from your initial purchase we have no obligation to send you replacement items even if previous ones were sent.

We recommend familiarizing yourself with our Terms and Conditions via vushstimulation.com/pages/warranty-refund-policy

GET IN TOUCH

Vush Pty Ltd Level I East, 170-180 Buckhurst Street, South Melbourne VIC 3205 AUS Website: vushstimulation.com Support: info@vushstimulation.com

FOLLOW OUR MOVEMENT AND EMBRACE #MORESELFLOVE

All trademarks are property of Vush Pty Ltd Designed in Australia, made with love in China

