WARNUNG: - Außerhalb der Reichweite von Kindern aufbewahren - Nicht auf gereizter Haut anwenden. Beenden Sie die Anwendung, wenn Hautreizungen auftreten. - Seien Sie vorsichtig bei der Anwendung um die Augen herum. - Spülen Sie den Trimmerkopf nicht mit Wasser ab. - Gerät nicht unter Wasser tauchen. - Bei Nichtgebrauch an einem kühlen, trockenen Ort aufbewahren. - Batterie nicht unsachgemäß anschließen, aufladen oder ins Feuer werfen. Der Akku kann explodieren oder auslaufen. - Entsorgen Sie alte Batterien gemäß allen geltenden örtlichen Vorschriften.

[EN] FACIAL HAIR REMOVER

DIRECTIONS: 1. Remove Cap 2. Slide the switch located on the side of the unit upward into the “ON” position. The light will automatically turn on when the unit is “ON”. 3. Gently press the head of the unit flat against your skin. The unit should not be on an angle. Proceed making small circular motions to remove unwanted hair. NOTE: It is normal for the head to become warm with use. CLEANING: - Twist the rotating hair removal head counter-clockwise and lift off. - After each use, clean the head by using a brush (included) to wipe away the hair residue. - Empty any hair from the body of the unit by turning it over and gently tapping the sides. - To put the hair removal head back on the unit, line up the “groove” indicators on the cap with those on the unit and twist clockwise. INSTALLING / CHANGING BATTERY: - Remove the cap. - Grab the upper section of the unit with one hand, the bottom half with the other, and pull apart to reveal the battery chamber. - Place 1 AA battery into the compartment, making sure the positive pole (+) is facing the bottom of the unit. - Slide/snap the unit’s bottom casing back into place. NOTE: Battery not included. TIPS & POINTERS: - For superior results, use on half 1/4 in length or less - If the unit begins to slow down, clear the hair removal head and body of any hair residue. If the unit is still running slow change the battery. - Gentle enough to use every day. - For airbrush-like make-up application, use daily. NOTE: Prior to first use, test the device on a small area. If any sensitivity or allergic reactions occur, discontinue use immediately. Do not use your device on sensitive or irritated skin.

WARNING: - Keep out reach of children - Do not use on irritated skin. Discontinue use if skin irritation occurs. - Exercise caution when using around eyes. - Do not rinse trimmer head water. - Do not submerge unit under water. - Store in a cool dry place when not in use. - Do not connect battery improperly, charge, or dispose of in fire. Battery may explode or leak. - Dispose of old batteries according to all applicable local regulations.

HAIR-REM-FACE_Manual

Brand : ZOË AYLA

Designer : Marie

Dieline: CUT FOLD

Process: BLACK

Notes:
- Multilingual Manual for packaging HAIR-REN-FACE
- Double-sided, Black and white
- Insert this manual into the packaging

Dimensions:

Flat size: (W)480mm x (H)145mm

Final (folded): (W)80mm x (H)145mm