

# LELO

## SMART WAND™ 2

USER MANUAL

BEDIENUNGSANLEITUNG

MANUEL D'UTILISATION

MANUAL DE USUARIO

MANUALE D'USO

使用指南 - 使用說明書



**INTENSE, ALL-ENCOMPASSING PLEASURE  
SHOULD NEVER BE TAKEN FOR GRANTED.  
USE IT OFTEN, WISELY & WITH CARE.**


Congratulations on acquiring SMART WAND 2. Before getting more closely acquainted with it, please take a moment to look through this user manual.

**IMPORTANT:** Your pleasure object has been locked for transportation. To unlock, simply connect the charger or see below.

## **GETTING STARTED**


- Before first use, charge your SMART WAND 2 for 2 hours.
- Unlock by pressing and holding the + and - buttons simultaneously for 3 seconds until the light turns on.
- Press + button to turn on; press again to increase the vibration strength.
- Press ( ) button to switch between the 10 vibration patterns.
- Press – button to reduce vibration strength.
- Press and hold ( ) button to turn off.

## GETTING TO KNOW YOUR SMART WAND 2




## USING SMART WAND 2

- How to hold



## CHARGING YOUR SMART WAND 2

- Insert the DC plug into the DC port at the base of your SMART WAND 2.
- Insert the mains plug into a wall socket. The LED on the interface of your SMART WAND 2 will pulse to indicate it is charging. When it is fully charged (after c. 1.5 hours), the LED will emit a steady glow.
- When the battery is running low, the LED on your SMART WAND 2 will emit a blinking white light.



**Only use original chargers provided by LELO with your SMART WAND 2.**

## **CLEANING, STORAGE, AND SAFETY**

- Using SMART WAND 2 with hand creams or silicone-based lubricants may make the silicone permanently tacky.
  - SMART WAND 2 is fully waterproof, making cleaning simple. Rinse and spray with LELO Toy Cleaner, then rinse again and allow to dry.
  - Always clean your SMART WAND 2 thoroughly before and after each use. You can wash the silicone with warm water and antibacterial soap, rinse with clean hot water and pat dry with a lint-free cloth or towel. Never use cleansers containing alcohol, petrol or acetone.
  - Avoid leaving your SMART WAND 2 in direct sunlight and NEVER expose it to extreme heat.
- Store your SMART WAND 2 in a dust-free place and keep it away from products of other materials.

## **TROUBLESHOOTING**

**The LED on your SMART WAND 2 does not pulse when the charger is connected:**

- The battery is drained and will require several minutes to acknowledge that it is being charged.
- The charger is not properly connected. Check wall and DC sockets.

**Your SMART WAND 2 does not activate when the center button is pressed:**

- The battery is empty. Recharge your SMART WAND 2.
- The interface of your SMART WAND 2 is locked. Hold down + and – for 5 seconds.

If you experience any other problems with your SMART WAND 2 or if you have any questions regarding operation, please contact: **customer care@lelo.com**



## SPECIFICATIONS

### MATERIALS

Silicone, PC, ABS

### SIZE

304 x 80 x 60 mm / 11.97 x 3.14 x 2.36 in

### WEIGHT

383 g / 0.84 lb

### BATTERY

Li-Ion 1200/1050mA 3.7V

### CHARGING

2.5h at 5.0V 750mA

### USER TIME

Up to 4 hours

### STANDBY

90 days

### FREQUENCY

80Hz

### INTERFACE

3-buttons

## **REGISTER WARRANTY**

To activate your 1-Year Limited Warranty, register the number provided on the LELO Authenticity Card at [LELO.COM/SUPPORT](https://LELO.COM/SUPPORT).

## **1-YEAR WARRANTY**

LELO warrants this pleasure object for a period of ONE (1) YEAR, after the date of original purchase, against defects due to faulty workmanship or materials. The warranty covers working parts that affect the function of the pleasure object. It does NOT cover cosmetic deterioration caused by fair wear and tear or damage caused by accident, misuse or neglect. Any attempt to open or take apart the pleasure object (or its accessories) will void the warranty. If you discover a defect and notify LELO during the warranty period, LELO will, at its discretion, replace the pleasure object free of charge. Claims under warranty must be supported by reasonable evidence of the date of claim is within the warranty period. To validate your warranty, please keep your original purchase receipt together with these warranty conditions for the duration of the warranty period. To claim your warranty, you must log in to your account at [LELO.COM](https://LELO.COM) then select the option to make a warranty claim. Shipping costs are non-refundable. This undertaking is in addition to consumer's statutory rights and does not affect those rights in any way.

## DISPOSAL INFORMATION

**Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):**

The crossed-out dustbin symbol indicates that this pleasure object should not be treated as household waste, but rather be brought to the appropriate collection point for recycling of electrical and electronic equipment.



**Disclaimer:** Users of this product do so at their own risk. Neither LELO nor its retailers assume any responsibility or liability for the use of this product. Changes or Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

**Model may be changed for improvements without notice.**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**RF exposure statement:** This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

© 2019 LELOi AB. ALL RIGHTS RESERVED.

DESIGNED AND DEVELOPED BY LELO SWEDEN

MANUFACTURED FOR LELO IN CHINA

**WEBSITE:** [WWW.LELO.COM](http://WWW.LELO.COM)

**SUPPORT:** [CUSTOMERCARE@LELO.COM](mailto:CUSTOMERCARE@LELO.COM)

**[www.lelo.com](http://www.lelo.com)**