

Fillerina 12HA Densifying-Filler Intensive Treatment

Fillerina 12HA Densifying-Filler Intensive Treatment shall be used every day for 14 days, in the morning or evening, depending on individual needs and habits. To promote Fillerina action, it is recommended to apply the product on clean skin, free from sebum and impurities.

Application Instructions:

1. Drink two glasses of water before the application of Fillerina Gel to facilitate its action.
2. Clean the skin and free it from sebum and impurities.
3. Draw up 2 ml of Double Filler Gel with the special Dispenser/Applicator and release it accurately onto the desired areas.
4. Leave the gel to work for 10 minutes. Do not carry out rotating massages or movements. With the palm of the hands, pat in the remaining product to complete the application.
5. Draw up 1 - 2 ml of Nourishing Film and apply it all over face and neck.
6. Tap gently to help the absorption.

Warnings:

For external use only. This is a dermo-cosmetic treatment. Avoid contact with the eyes. Do not swallow. Do not inject. Keep out of the reach of children. Keep away from light and heat.