

Read the instructions carefully as well as the safety guidelines before use.

1. GENERAL DESCRIPTION

- 1. Handle
 - 2. On/Off switch (+/-)
 - 3. Hair iron (+/-)
 - 4. Accessory locking - and unlocking - ring
 - 5. Swivel power lead
- ACCESSORIES**
- 6. Hair iron (16 mm in diameter)
 - 7. Hair iron (+/-)
 - 8. Extra large curling iron
 - 9. Massage hair brush
 - 10. Straightening plate
 - 11a. Crimp/straightener crimping position plates
 - 11b. Crimp/straightener straightening position plates
 - 12. Crimp/straightener straightening plates
 - 13. Storage case
 - 14. 2 elite bobby pins

2. SAFETY

• For your safety, this appliance complies with the applicable standards and regulations. See **Wiring Voltage, Safety Directive, electromagnetic compatibility, Environmental...**

• The appliance's accessories become very hot during use. Avoid contact with the hot parts of the appliance.

• Check that the voltage of your electricity supply matches the voltage of your appliance. Any error when connecting the appliance can cause irreparable harm, not covered by the guarantee.

• For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask for installer for advice.

• The installation of the appliance and its use must however comply with the standards in force in your country.

• **WARNING:** do not use this appliance near bathtubs, showers, basins or other vessels containing water.

• When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.

• This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have not been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children must be supervised to ensure that they do not play with the appliance.

• This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

• If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

• Stop using your appliance and contact an Authorised Service Centre if:

- your appliance has failed;
- it does not work correctly;
- the plug or cord is damaged;
- when you leave the room, even momentarily;
- do not use the cord if damaged;
- do not immerse or put under running water, even for cleaning purposes;
- do not hold the appliance by the casing, which is hot, but by the handle;
- do not plug by pulling the cord, rather pull out by the plug;
- do not clean with abrasive or corrosive products;
- do not use at temperatures below 0°C and above 35°C.

GUARANTEE:

Your appliance is designed for use in the home only. It should not be used for professional purposes. The guarantee becomes null and void in the case of improper usage.

3. BEFORE FIRST USE

In order to use the device, attach the accessories to the appliance only when it is cool. Allow access to the device before storing in the case.

3a) Placing and removing the Irons:
Follow the same procedure as for the ironing board (Fig. 1). To remove, follow the inverse procedure.

3b) Placing and removing the brushes:
Follow the same procedure as for the ironing board (Fig. 2).

3c) Placing and removing the straightener on the handle (Fig. 3):
To remove the straightener, slide it in the opposite sense.

3d) Placing the crimp/straightener (Fig. 4):
Follow the same procedure as for the ironing board (Fig. 2). To remove, follow the inverse procedure (Fig. 3b) to use the straightening plates.

PLUGGING IN YOUR HAIR STYLER:

• Place the power cord on the handle, place the appliance in a stable position on its rest, or flat surface.

• Plug in and turn on the On/Off switch to On (position 1). The "Power" light will come on and the heating element will heat up (Fig. 2).

• Wait a few minutes to allow your hair to reach its working temperature (1-3 min for the "iron" accessories; 6 min for the crimping plates).

4. OPERATION

• Use a dry, clean, untangled, DRY hair (to avoid damaging your hair).

Fig. 6 - For tight curls

Fig. 7 - For crimped hair

Fig. 8 - For loose curls

Fig. 9 - For hair lapses, 2x 3 across

• Press the lever to open the tong, then slip the tips of the hair between the roller and the tong.

• Turn the roller to close the tong. Check that all the hair tips are correctly wound under the tong, in the direction of the curl.

• Remove the plastic cover from the handle.

• Turn the iron in place for 10 to 15 seconds, then until carefully.

• For a more natural, wavy look: lightly comb or comb your hair once the hair has cooled.

PROFESSIONAL TIPS:

• To create extra volume: divide your curls using fingers.

• To obtain really tight curls: wind small sections of hair at a time.

• For softer curl control: on more heat.

• Turn the iron in the direction of the curl.

• Use a hair spray to prevent the hair and tongue of the iron from getting too hot.

• Repeat the procedure with different sections of hair to form more curls.

PROFESSIONAL TIPS:

• To avoid kinks in long sections of hair, use a smooth, continuous movement.

• To enhance the effect, you can apply styling mouse before crimping.

Fig. 11b - For straightened hair

Fig. 11a - For crimped hair

Fig. 12 - For loose hair

Fig. 13 - For hair lapses

Fig. 14 - For hair lapses, 2x 3 across

Fig. 15 - For hair lapses, 2x 15 seconds, then until carefully.

2b) Spiral brush
• Take a straight brush and turn it around the brush.

• Turn the iron in place for 10 to 15 seconds, then until carefully.

PROFESSIONAL TIPS:

• To obtain the best results, turn the iron towards the tips of the hair.

• To enhance the effect, you can apply styling mouse before crimping.

Fig. 16 - Straightener

Fig. 17 - For straight hair

Fig. 18 - For hair lapses

Fig. 19 - For hair lapses, 2x 3 across

Fig. 20 - For hair lapses, 2x 15 seconds, then until carefully.

PROFESSIONAL TIPS:

• Avoid kinks in long sections of hair, use a smooth, continuous movement.

• To enhance the effect, you can apply styling mouse before straightening.

Fig. 21 - For straight hair

Fig. 22 - For hair lapses

Fig. 23 - For hair lapses, 2x 3 across

Fig. 24 - For hair lapses, 2x 15 seconds, then until carefully.

PROFESSIONAL TIPS:

• Avoid kinks in long sections of hair, use a smooth, continuous movement.

• To enhance the effect, you can apply styling mouse before straightening.

Fig. 25 - For straight hair

Fig. 26 - For hair lapses

Fig. 27 - For hair lapses, 2x 3 across

Fig. 28 - For hair lapses, 2x 15 seconds, then until carefully.

PROFESSIONAL TIPS:

• Avoid kinks in long sections of hair, use a smooth, continuous movement.

• To enhance the effect, you can apply styling mouse before straightening.

Fig. 29 - For straight hair

Fig. 30 - For hair lapses

Fig. 31 - For hair lapses, 2x 3 across

Fig. 32 - For hair lapses, 2x 15 seconds, then until carefully.

PROFESSIONAL TIPS:

• Avoid kinks in long sections of hair, use a smooth, continuous movement.

• To enhance the effect, you can apply styling mouse before straightening.

Fig. 33 - For straight hair

Fig. 34 - For hair lapses

Fig. 35 - For hair lapses, 2x 3 across

Fig. 36 - For hair lapses, 2x 15 seconds, then until carefully.

PROFESSIONAL TIPS:

• Avoid kinks in long sections of hair, use a smooth, continuous movement.

• To enhance the effect, you can apply styling mouse before straightening.

Fig. 37 - For straight hair

Fig. 38 - For hair lapses

Fig. 39 - For hair lapses, 2x 3 across

Fig. 40 - For hair lapses, 2x 15 seconds, then until carefully.

PROFESSIONAL TIPS:

• Avoid kinks in long sections of hair, use a smooth, continuous movement.

• To enhance the effect, you can apply styling mouse before straightening.

Fig. 41 - For straight hair

Fig. 42 - For hair lapses

Fig. 43 - For hair lapses, 2x 3 across

Fig. 44 - For hair lapses, 2x 15 seconds, then until carefully.

PROFESSIONAL TIPS:

• Avoid kinks in long sections of hair, use a smooth, continuous movement.

• To enhance the effect, you can apply styling mouse before straightening.

Fig. 45 - For straight hair

Fig. 46 - For hair lapses

Fig. 47 - For hair lapses, 2x 3 across

Fig. 48 - For hair lapses, 2x 15 seconds, then until carefully.

PROFESSIONAL TIPS:

• Avoid kinks in long sections of hair, use a smooth, continuous movement.

• To enhance the effect, you can apply styling mouse before straightening.

Fig. 49 - For straight hair

Fig. 50 - For hair lapses

Fig. 51 - For hair lapses, 2x 3 across

Fig. 52 - For hair lapses, 2x 15 seconds, then until carefully.

PROFESSIONAL TIPS:

• Avoid kinks in long sections of hair, use a smooth, continuous movement.

• To enhance the effect, you can apply styling mouse before straightening.

Fig. 53 - For straight hair

Fig. 54 - For hair lapses

Fig. 55 - For hair lapses, 2x 3 across

Fig. 56 - For hair lapses, 2x 15 seconds, then until carefully.

PROFESSIONAL TIPS:

• Avoid kinks in long sections of hair, use a smooth, continuous movement.

• To enhance the effect, you can apply styling mouse before straightening.

Fig. 57 - For straight hair

Fig. 58 - For hair lapses

Fig. 59 - For hair lapses, 2x 3 across

Fig. 60 - For hair lapses, 2x 15 seconds, then until carefully.

PROFESSIONAL TIPS:

• Avoid kinks in long sections of hair, use a smooth, continuous movement.

• To enhance the effect, you can apply styling mouse before straightening.

Fig. 61 - For straight hair

Fig. 62 - For hair lapses

Fig. 63 - For hair lapses, 2x 3 across

Fig. 64 - For hair lapses, 2x 15 seconds, then until carefully.

PROFESSIONAL TIPS:

• Avoid kinks in long sections of hair, use a smooth, continuous movement.

• To enhance the effect, you can apply styling mouse before straightening.

Fig. 65 - For straight hair

Fig. 66 - For hair lapses

Fig. 67 - For hair lapses, 2x 3 across

Fig. 68 - For hair lapses, 2x

