














**IT** Scaldabiberon  
**ES** Calienta Biberones  
**EN** Bottle Warmer  
**FR** Chauffe-Biberon  
**DE** Flaschenwärmer  
**PT** Aquecedor de Biberões  
**GR** Θερμοφόρα μπιμπερό



**IT** Manuale di Istruzioni  
**ES** Manual de Instrucciones  
**EN** Instruction Manual  
**FR** Manuel d'Instructions

**DE** Bedienungsanleitung  
**PT** Manual de instruções  
**GR** Εγχειρίδιο οδηγιών





**BOX CONTENTS (FIG 1, 2, 3, A, B, C, D, E, F)**

- A. Bottle warmer main body
- B. Ring
- C. Lift out basket
- D. 12V car adapter
- E. Plug
- F. Measuring cup

**IMPORTANT SAFETY NOTES**

Keep the instruction sheet for future reference:

- Only use the appliance indoors/inside the car. NEVER use it outdoors.
- Ensure the voltage is compatible with the electricity supply.
- Always add water first before switching the unit on.
- Use the appliance away from children. Store the appliance in a safe place away from children.
- Once finishing using the bottle warmer, unplug, empty the water from the device and store it in a dry place. Keep it away from children's reach. Note the surface of the heating element is subject to residual heat after each use.
- DO not immerse any fixed or removable parts in water to avoid injury.
- Follow the heating guidelines suggested for child's safety during feeding.
- Do not use the appliance with a damaged part. If the damage is from a new unit, please return the unit immediately to the store.
- The supplied accessories of the bottle warmer should only be used.

**CUSTOMER SERVICE**

If you are experiencing problems with the Nuvita 1165 bottle warmer immediately contact the establishment where the item was purchased.

**SETTING GUIDE**

The table indicates standard and suggestive heating times, that may vary according to the size of the bottle, the temperature of the water inside in the bottle warmer and the initial temperature of the food.

**CAUTION:** Always check temperature of liquid before feeding to the baby.

## TIME CHART FOR HOME USE

GENTLE DEFROST		WARMING		FAST WARMING	
START TEMPERATURE	-5°C	20°C	5°C	20°C	5°C
CONTENT	HEAT TIME (MIN)	RECOM-MENDED WATER (ML)	HEAT TIME (MIN)	RECOM-MENDED WATER (ML)	HEAT TIME (MIN)
60ml	40	12	140	18	140
90ml	45	16	20	20	20
120ml	50	18	23	23	23
150ml	50	20	25	25	25
180ml	55	23	28	28	28
210ml	55	25	32	32	32
250ml	65	28	35	35	35
280ml	65	30	37	37	37
300ml	80	34	40	40	40
330ml	85	38	45	45	45

## FOOD JAR WARMING

20°C		5°C	
START TEMPERATURE	RECOM-MENDED WATER (ML)	HEAT TIME (MIN)	RECOM-MENDED WATER (ML)
CONTENT	HEAT TIME (MIN)	HEAT TIME (MIN)	RECOM-MENDED WATER (ML)
80g	25	32	150
120g	28	35	150
160g	39	45	150

(\*) At the end of the GENTLE DEFROST cycle, the final temperature reached will be about 20°C.

(\*\*) At the end of the WARMING AND FAST WARMING cycle, the final temperature reached will be about 37°C, the ideal temperature for administering food to the baby, as it is similar to the temperature of breast milk.

To reach higher temperatures, use the Fast Warming mode by increasing the times shown in the Table.

## TIME CHART FOR CAR USE

GENTLE DEFROST		WARMING			FAST WARMING		
START TEMPERATURE	-5°C	20°C		5°C	20°C		5°C
CONTENT	HEAT TIME (MIN)	RECOM-MENDED WATER (ML)	HEAT TIME (MIN)	RECOM-MENDED WATER (ML)	HEAT TIME (MIN:SEC)	RECOM-MENDED WATER (ML)	HEAT TIME (MIN:SEC)
60ml	40		13	130	21	130	7:30
90ml	45		17	24			10:00
120ml	50		22	33			10:30
150ml	50		25	38			11:00
180ml	55		28	40			11:30
210ml	55		30	43			12:30
250ml	65		35	45			14:00
280ml	65		38	55			14:30
300ml	80		42	60			15:30
330ml	85		47	65			16:00

## FOOD JAR WARMING

20°C		5°C	
START TEMPERATURE	RECOM-MENDED WATER (ML)	HEAT TIME (MIN)	RECOM-MENDED WATER (ML)
CONTENT			
80g	48		57
120g	68		69
160g	82		90
			150

(\*) At the end of the GENTLE DEFROST cycle, the final temperature reached will be about 20°C.

(\*\*) At the end of the WARMING AND FAST WARMING cycle, the final temperature reached will be about 37°C, the ideal temperature for administering food to the baby, as it is similar to the temperature of breast milk.

To reach higher temperatures, use the Fast Warming mode by increasing the times shown in the Table.

## **DEVICE SETUP**

---

### **FOR USE AT HOME**

1. Before using the bottle warmer, ensure the mains outlet is of correct voltage.
2. The bottle warmer must be used out of reach of children. Place the bottle warmer on a stable surface.
3. Make sure that the knob is positioned on the OFF symbol and plug the cable to a power outlet.
4. Choose one of the heating options and set times and volumes according to the table in the manual.

### **FOR USE IN CAR**

1. Before using the bottle warmer, ensure the mains outlet is of correct voltage.
2. The bottle warmer must be used out of reach of children. Place the bottle warmer on a stable surface.
3. Connect the car adapter to the cigarette lighter socket of the automobile (12V DC) See. FIG.3.
4. Choose one of the heating options and set times and volumes according to the table in the manual.

### **CAUTION**

- During operation, the device indicator light will continuously switch off and on every time the temperature drops with respect to the selected setting, until the device is manually switched off.
- Always ensure to avoid any water overflow once a filled baby bottle is inside.
- Do not use the bottle warmer while the car is moving.
- Always use the bottle warmer with water inside it.
- Re-heating solid food is not recommended.
- The "automatic temperature maintenance" mode of the DEFROST, BABY BOTTLE WARMING functions will work continuously unless it is manually disconnected by unplugging the power socket or until the water runs out.
- Before heating, remove the protective cap and the teat from the bottles and remove the lid from the jars.

## **OPERATION**

---

Please refer to the SETTING GUIDE section for table of volume and warming times

### **GENTLE DEFROSTING**

1. Insert the basket and if necessary the adapter ring. See FIG.1. (A-B-C)  
NOTE: If the adapter ring does not fit loosely around the bottle, do not use.

2. Fill the tank with water as indicated in the GENTLE DEFROSTING table. Do not overflow.
3. Place the bottle or the jar inside the bottle warmer.
4. Turn the knob to the defrost position. See **FIG.4**.
5. When the indicative time specified in the table ends, turn off the device by turning the knob back to the OFF position. See **FIG.8**, disconnect the cable from the power outlet and empty any remaining water.

Please note that this function doesn't substitute the Warming function because at the end of the gentle warming cycle the final temperature will reach max 20°C. To feed the food later, use one of the reheat functions.

## **WARMING OF BABY BOTTLES (HOME USE)**

1. Insert the basket and if necessary the adapter ring. See **FIG.1**.  
NOTE: If the adapter ring does not fit loosely around the bottle, do not use.
2. Fill the tank with water as indicated in the WARMING Table. Do not overflow.
3. Place the bottle without the teat and protective cap inside the bottle warmer.
4. Rotate the knob to the bottle position. See **FIG.5**. The light turns on to indicate that the warming cycle is still on or a cycle is running.
5. When the light switches off, it does not indicate that the heating cycle has ended, but simply that the device has reached the set temperature. Remove the bottle from the device when the indicative time shown in the Table has expired.
6. Shake the bottle slowly to distribute the heat evenly. Pour a few drops on the back of your hand to make sure that the temperature of the milk is not too high before feeding the baby.
7. When the indicative time shown in the WARMING table ends, turn the knob to the OFF position. See **FIG.8**, disconnect the cable from the power outlet and empty any remaining water.
8. **KEEP THE BABY BOTTLE WARM:** To maintain the temperature, leave the bottle inside the basket and with the knob positioned on the bottle position. The indicator light of the device will turn off and turn on continuously each time the temperature drops with respect to the selected setting, until the device is manually turned off or when the water inside it runs out.

## **WARMING OF BABY BOTTLES (CAR USE)**

1. Insert the basket and if necessary the adapter ring. See **FIG.1**.  
NOTE: If the adapter ring does not fit loosely around the bottle, do not use.
2. Fill the tank with water as indicated in the car WARMING table. Do not overflow.
3. Place the bottle without the teat and protective cap inside the bottle warmer.

4. Rotate the knob to the bottle position. See **FIG.10**. The light turns on to indicate that the warming cycle is still on or a cycle is running.
5. Remove the jar from the basket only when the indicative time shown in the Warming Table has ended.
6. Shake the bottle slowly to distribute the heat evenly. Pour a few drops on the back of your hand to make sure that the temperature of the milk is not too high before feeding the baby.
7. When the baby bottle has been removed, turn the knob to the OFF position. See **FIG.8**, disconnect the cable from the power outlet and empty any remaining water.
8. **KEEP THE BABY BOTTLE WARM:** To maintain the temperature, leave the bottle inside the basket and with the knob positioned on the bottle position. The indicator light of the device will turn off and turn on continuously each time the temperature drops with respect to the selected setting, until the device is manually turned off or when the water inside it runs out.

## **WARMING OF BABY FOOD JARS (ONLY FOR HOME USE)**

1. Insert the basket.
2. Remove the food jar cover. Place the jar inside the basket and fill the tank, as indicated in the Table, with enough water to reach the same level of the jar. Do not allow the water to enter the jar.
3. Rotate the knob to the jar position. See **FIG.6**. The light turns on to indicate that the warming cycle is still on or a cycle is running.
4. If necessary, remove the basket slightly and mix the contents of the jar, so as to equalize the temperature.
5. Remove the jar from the basket only when the indicative time shown in the Food Jar Warming Table has ended.
6. Once the jar has been removed, turn the knob back to OFF position. See **FIG.8**, disconnect the cable from the power outlet and empty any remaining water.

## **FAST WARMING**

This bottle warmer has a fast warming function that will warm the bottles and jars in a shorter time.

1. Insert the basket and if necessary the adapter ring. See **FIG.1**.  
NOTE: If the adapter ring does not fit loosely around the bottle, do not use.
2. Fill the tank with water as indicated in the FAST WARMING Table. Do not overflow.
3. Place the bottle without the teat and protective cap inside the bottle warmer.
4. Rotate the knob to the bottle position. See **FIG.7**. The light turns on to indicate that the fast warming cycle is on or a cycle is running.

5. When the indicative time specified in the table ends, remove the baby bottle from the device. Taking care not to burn yourself.
6. Shake the bottle slowly to distribute the heat evenly. Pour a few drops on the back of your hand to make sure that the temperature of the milk is not too high before feeding the baby.
7. Once the baby bottle has been removed, turn knob back to OFF position. See FIG.8., disconnect the cable from the power outlet and empty any remaining water.

## CONSECUTIVE CYCLES

This device has been designed to allow consecutive cycles without having to wait for the heating plate to cool. Change the water between one use and the next.

## NUTRITIONAL VALUES OF BREAST MILK

This device has been designed to gently heat milk and prevent overheating in order to retain breast milk nutrients. By following the Table of Volumes and Times shown in the manual, a suggestive temperature of 37° is ideal for administering food to the child.

## CLEANING

---

Disconnect the bottle warmer from the main power supply. Only clean once the warmer has cooled down. Clean the container and the outside part with a damp cloth. Do not use strong cleaning liquids. To reduce sediment deposits will recommend using bottled, filtered or previously boiled water.

### NOTE

*To remove limescale sediments it is recommended to mix 50ml of white alcohol vinegar with 50ml of plain water or dissolve a dose of citric acid in 200ml of cold water. Pour the solution into the device. Leave the solution to act until the limescale is completely dissolved. Do not use the device during this period. Repeat the cleaning operation in the presence of limescale or whenever the performance of the product appears less efficient.*

## WARRANTY - TERMS AND CONDITIONS

---

This product benefits of a warranty of 24 months on material and manufacturing defects, starting from the date of purchase (see sales slip). The warranty of 24 months does not include damages caused by the usual use of parts identified as "consumable" (e.g., batteries, brush heads or parts subject to usury). The legal guarantee of 24 months is void if: **1.** The product has undergone aesthetic damage due to improper use not in accordance with instructions in the manual. **2.** This product has been modified and/or tampered with. **3.** The cause of the failure was due to poor maintenance of the individual components

and/or accessories and/or supplies (e.g. oxidation and/or scaling due to the retention of water or other liquids, sediment blocking the sensor, leak of corrosive liquid from batteries). The following is excluded from the legal guarantee of 24 months: **1.** Costs related to replacements and/or repair of parts subject to wear or costs for ordinary maintenance of the product. **2.** The costs and risks involved in transporting the product to and from the store where you purchased or otherwise authorized collection centre to receive the products under warranty. **3.** Damage caused by or resulting from improper installation or improper use not in accordance with the directions in the instruction manual. **4.** Damage due to natural disasters, accidental events or adverse conditions not compatible with the product. **5.** Defects that have a negligible effect on product performance. The manufacturer, distributor and all the parties involved in the sale do not assume any liability for losses and economic damage from any malfunction of the product. In accordance with current regulations the manufacturer, distributor and all the parties involved in the sale are not responding in any case for damages, including direct, indirect ones, loss of net income, loss of savings and additional damage and other details consequences going beyond the damage caused by the breach of warranty, contract, strict liability, wrongdoing or due to other causes, resulting from the use or inability to use the product and/or paper and electronic documents, including the lack of service. For further information on the help service visit the website **[www.nuvitababy.com](http://www.nuvitababy.com)**



Il prodotto Nuvita 1165 Scaldabiberon e un marchio registrato da

El producto y el diseño del calentador digital de biberones Nuvita 1165 son marcas registradas de

The Nuvita 1165 Digital Bottle Warmer product and design are trademark by

Le produit et le design du chauffe-biberon numérique Nuvita 1165 sont une marque déposée de

Das Produkt und das Design des Nuvita 1165 Digital Bottle Warmer sind Warenzeichen von

O produto e design do aquecedor digital de garrafas Nuvita 1165 são marcas registradas da

To προϊόν και ο σχεδιασμός Nuvita 1165 Digital Bottle Warmer είναι εμπορικά σήματα  
κατατεθέντα

Anteprima Brands International,

1, St. Luke's Street, Gwardamangia, PTA1020 Pieta, Malta, Europe.

[www.nuvitababy.com](http://www.nuvitababy.com)

Fabbricato in Cina. Fabricado en China. Made in China. Fabriqué en Chine.

In China hergestellt. Fabricado na China. Κατασκευάζεται στην Κίνα.

Home use: 220V-240V / 320 Watts

Car use: 12V/100 Watts



## IT - PROTEGGI IL TUO PRODOTTO DAI DANNI PROVOCATI DAL CALCARO

Il calcare, quando si cristallizza, può danneggiare in modo irreparabile il tuo prodotto. Avendo un elevato potere isolante, quando si accumula potrebbe non riscaldare l'acqua in modo adeguato oppure il prodotto potrebbe spegnersi improvvisamente senza aver terminato l'impostazione selezionata, rendendo meno efficienti le sue prestazioni. Inoltre, sapevi che i depositi di calcare sono un terreno ideale per la formazione di batteri e altri microrganismi indesiderati? Esatto! Proprio così!

I depositi di calcare hanno una superficie ruvida e irregolare, pertanto le piccole cavità che si formano tra i cristalli, sono il luogo perfetto per l'atteggiamento dei batteri. Proteggi il tuo bambino da sostanze potenzialmente pericolose che rimarrebbero intrappolate nel calcare, se non rimosso con regolarità.

### SUGGERIMENTI PER LA PULIZIA DEL CALCARO:

- Collegare l'apparecchio prima di pulirlo.
- Per una semplice pulizia del tuo dispositivo, ti consigliamo di decalcificare con aceto bianco di alcol oppure acido cítrico.
- Mescolare 50 ml di aceto bianco di alcol con 50 ml di acqua naturale oppure sciogliere una dose di acido cítrico in 200 ml di acqua fredda. Versare la soluzione nell'apparecchio. Lasciare agire la soluzione fino a quando il calcare non verrà completamente disiolto; non utilizzare il dispositivo durante questo periodo. Alla fine della pulizia, rimuovere il liquido, risciacquare accuratamente il dispositivo ed asciugare con un panno morbido.
- Ripetere l'operazione di pulizia in presenza di calcare oppure ogni volta le prestazioni del prodotto appaiono meno efficienti.

## ES - PROTEJA SU PRODUCTO DEL DAÑO CAUSADO POR LA CALIZA

La cal, cuando se cristaliza, puede dañar irreparablemente su producto. Al tener un alto poder aislante, cuando se acumula puede no calentar el agua adecuadamente o el producto puede apagarse repentinamente sin haber terminado la configuración seleccionada, lo que hace que su rendimiento sea menos eficiente. Además, ¿sabía que los depósitos de la cal son un medio ideal para la formación de bacterias y otros microorganismos no deseados? ¡Exacto! ¡Así es!

Los depósitos de la cal tienen una superficie rugosa e irregular, por lo tanto, las pequeñas cavidades que se forman entre los cristales son el lugar perfecto para que las bacterias echen raíces. Proteja a su hijo de sustancias potencialmente peligrosas que podrían quedar atrapadas en la cal si no se eliminan regularmente.

### CONSEJOS DE LIMPIEZA DE CAL:

- Desenchufe el aparato antes de limpiarlo.
- Para una limpieza simple de su dispositivo, le recomendamos que lo descalcifique con vinagre de alcohol blanco o ácido cítrico.
- Mezcle 50 ml de vinagre de alcohol blanco con 50 ml de agua corriente o disuelva una dosis de ácido cítrico en 200 ml de agua fría. Vierta la solución en el aparato. Deje que la solución actúe hasta que la cal se disuelva por completo; no use el dispositivo durante este período. Al final de la limpieza, retire el líquido, enjuague bien el dispositivo y séquelo con un paño suave.
- Repita la operación de limpieza en presencia de la cal o cuando el rendimiento del producto parezca menos eficiente.

## EN - PROTECT YOUR PRODUCT FROM DAMAGE CAUSED BY LIMESTONE

Limestone, when it crystallizes, can irreparably damage your product. Having a high insulating power, when it accumulates it may not heat the water adequately or the product may suddenly switch off without having finished the selected setting, making its performance less efficient. Also, did you know that limestone deposits are an ideal medium for the formation of bacteria and other unwanted microorganisms? Exact! That's right!

Limestone deposits have a rough and uneven surface, therefore the small cavities that form between the crystals are the perfect place for bacteria to take root. Protect your child from potentially dangerous substances that would become trapped in limestone if not removed regularly.

### LIMESTONE CLEANING TIPS:

- Unplug the appliance before cleaning it.
- For easy cleaning of your device, we recommend that you descale it with white alcohol vinegar or citric acid.
- Mix 50 ml of white alcohol vinegar with 50 ml of plain water or dissolve a dose of citric acid in 200 ml of cold water. Pour the solution into the appliance. Leave the solution to act until the limestone is completely dissolved; do not use the device during this period. At the end of the cleaning, remove the liquid, rinse the device thoroughly and dry with a soft cloth.
- Repeat the cleaning operation in the presence of limestone or whenever the product performance appears less efficient.

## FR - PROTÉGEZ VOTRE PRODUIT DES DOMMAGES CAUSÉS PAR LE CALCAIRE

Le calcaire, lorsqu'il cristallise, peut endommager irrémédiablement votre produit. Ayant un pouvoir isolant élevé, lorsqu'il s'accumule, il peut ne pas chauffer l'eau de manière adéquate ou le produit peut s'éteindre soudainement sans avoir terminé le réglage sélectionné, rendant ses performances moins efficaces. Aussi, saviez-vous que les dépôts de calcaire sont un milieu idéal pour la formation de bactéries et autres micro-organismes indésirables? Exact! C'est vrai!

Les dépôts de calcaire ont une surface rugueuse et inégale, donc les petites cavités qui se forment entre les cristaux sont l'endroit idéal pour que les bactéries prennent racine. Protégez votre enfant des substances potentiellement dangereuses qui seraient emprisonnées dans le calcaire si elles ne sont pas éliminées régulièrement.

### CONSEILS DE NETTOYAGE DE LA LIME:

- Débranchez l'appareil avant de le nettoyer.
- Pour un nettoyage simple de votre appareil, nous vous recommandons de le détartrer avec du vinaigre d'alcool blanc ou de l'acide citrique.
- Mélangez 50 ml de vinaigre d'alcool blanc avec 50 ml d'eau ordinaire ou dissolvez une dose d'acide citrique dans 200 ml d'eau froide. Versez la solution dans l'appareil. Laisser agir la solution jusqu'à ce que le calcaire soit complètement dissous; n'utilisez pas l'appareil pendant cette période. À la fin du nettoyage, retirez le liquide, rincez soigneusement l'appareil et séchez-le avec un chiffon doux.
- Répéter l'opération de nettoyage en présence de calcaire ou chaque fois que les performances du produit semblent moins efficaces.

## DE - SCHÜTZEN SIE IHR PRODUKT VOR SCHÄDEN DURCH KALKSTEIN

Wenn Kalkstein kristallisiert, kann er Ihr Produkt irreparabel beschädigen. Bei einer hohen Isolationseistung erwärmt sich das Wasser möglicherweise nicht ausreichend, wenn es sich ansammelt, oder das Produkt schaltet sich plötzlich ab, ohne die ausgewählte Einstellung abgeschlossen zu haben, wodurch die Leistung weniger effizient wird. *Wussten Sie auch, dass Kalksteinablagerungen ein ideales Medium für die Bildung von Bakterien und anderen unerwünschten Mikroorganismen sind? Genau! Das stimmt!*

Kalksteinablagerungen haben eine rauhe und unebene Oberfläche, daher sind die kleinen Hohlräume, die sich zwischen den Kristallen bilden, der perfekte Ort für Bakterien, um Wurzeln zu schlagen. Schützen Sie Ihr Kind vor potenziell gefährlichen Substanzen, die sich in Kalkstein verfangen würden, wenn sie nicht regelmäßig entfernt würden.

### TIPPS ZUR KALKREINIGUNG:

- Ziehen Sie den Stecker aus der Steckdose, bevor Sie das Gerät reinigen.
- Zur einfachen Reinigung Ihres Geräts empfehlen wir, es mit weißem Alkoholgeist oder Zitronensäure zu entkalken.
- Mischen Sie 50 ml weißen Alkoholgeist mit 50 ml klarem Wasser oder lösen Sie eine Dosis Zitronensäure in 200 ml kaltem Wasser. Gießen Sie die Lösung in das Gerät. Lassen Sie die Lösung einwirken, bis sich der Kalkstein vollständig aufgelöst hat. Verwenden Sie das Gerät während dieser Zeit nicht. Entfernen Sie am Ende der Reinigung die Flüssigkeit, spülen Sie das Gerät gründlich aus und trocknen Sie es mit einem weichen Tuch.
- Wiederholen Sie den Reinigungsvorgang in Gegenwart von Kalkstein oder wenn die Produktleistung weniger effizient erscheint.

## PT - PROTEJA SEU PRODUTO DE DANOS CAUSADOS POR LIMESTONE

O calcário, quando cristaliza, pode danificar irreparavelmente o seu produto. Com um alto poder isolante, quando acumulado, pode não aquecer a água adequadamente ou o produto pode desligar repentinamente sem ter finalizado a configuração selecionada, tornando seu desempenho menos eficiente. *Além disso, você sabia que os depósitos de calcário são um meio ideal para a formação de bactérias e outros microorganismos indesejados? Exato! Está certo!*

Os depósitos de calcário têm uma superfície áspera e irregular, portanto, as pequenas cavidades que se formam entre os cristais são o local perfeito para as bactérias se enraizarem. Proteja seu filho de substâncias potencialmente perigosas que ficariam presas em calcário se não fossem removidas regularmente.

### DICAS DE LIMPEZA DE LIMÃO:

- Desconecte o aparelho antes de limpá-lo.
- Para uma limpeza simples do seu dispositivo, recomendamos descalcificá-lo com vinagre de álcool branco ou ácido cítrico.
- Misture 50 ml de vinagre de álcool branco com 50 ml de água pura ou dissolva uma dose de ácido cítrico em 200 ml de água fria. Despeje a solução no aparelho. Deixe a solução agir até que o calcário esteja completamente dissolvido; não use o dispositivo durante esse período. No final da limpeza, remova o líquido, lave o dispositivo cuidadosamente e seque com um pano macio.

• Repita a operação de limpeza na presença de calcário ou sempre que o desempenho do produto parecer menos eficiente.

## GR - ΠΡΟΣΤΑΤΕΥΣΤΕ ΤΟ ΠΡΟΪΟΝ ΣΑΣ ΑΠΟ ΖΗΜΙΑ ΠΟΥ ΠΡΟΚΑΛΕΙ Η ΛΙΜΕΣΤΟΝ

O ασβεστόλιθος, όταν κρυσταλλώνεται, μπορεί να καταστρέψει ανεπάρθιμα το προϊόν σας. Εχοντας υψηλή μονωτική ιούχη, όταν συσσωρέεται μπορεί να μην θερμαίνει σωστά το νερό ή το προϊόν μπορεί ξαφνικά να απενεργοποιηθεί χωρίς να έχει τελείωσει την επιλεγμένη ρύθμιση, καθιστώντας την απόδοσή του λιγότερο αποτελεσματική. *Επίσης ξέρατε ότι οι εναποθέσεις ασβεστόλιθων είναι το ιδανικό μέρος για το συγκατόπιο βακτηρίων και άλλων ανεπιθύμητων μικροοργανισμών: Ακριβής! Σωστά!*

Οι εναποθέσεις ασβεστόλιθου έχουν μια τραχιά και ανύμαλη επιφάνεια, επομένως οι μικρές κοιλότητες που σχηματίζονται μεταξύ των κρυστάλλων είναι το ιδανικό μέρος για να ριζωθούν τα βακτηρία. Προστατέψτε το παιδί σας από δυνητικά επικίνδυνες ουσίες που θα παγιδευτούν σε ασβεστόλιθο εάν δεν αφαιρούνται τακτικά.

### ΣΥΜΒΟΥΛΕΣ ΚΑΘΑΡΙΣΜΟΥ LIME:

- Αποσυνδέστε τη συσκευή πριν την καθαρίσετε.
- Για εύκολο καθάρισμα της συσκευής σας, σας συνιστούμε να την αφαλάσσετε με ξύδι λευκού αλκοόλ ή κιτρικό οξύ.
- Ανακατέψτε 50 ml λευκού ξύδιού αλκοόλης με 50 ml απλού νερού ή διαλύστε μια δόση κιτρικού οξέος σε 200 ml κρύου νερού. Ρίξτε το διάλυμα στη συσκευή. Αρήστε το διάλυμα να δράσει μέχρι να διαλυθεί εντελώς ο ασβεστόλιθος. Μην χρησιμοποιείτε τη συσκευή κατά τη διάρκεια αυτής της περιόδου. Στο τέλος του καθαρισμού, αφαιρέστε το υγρό, ξεπλύνετε καλά τη συσκευή και στεγνώστε με ένα μαλακό πανί.
- Επαναλάβετε τη διαδικασία καθαρισμού παρουσία ασβεστόλιθου ή όποτε η απόδοση του προϊόντος φαίνεται λιγότερο αποτελεσματική.



Il prodotto Nuvita 1165 Scaldabiberon è un marchio registrato da El producto y el diseño del calentador digital de biberones Nuvita 1165 son marcas registradas de

The Nuvita 1165 Digital Bottle Warmer product and design are trademark by Le produit et le design du chauffe-biberon numérique Nuvita 1165 sont une marque déposée de

Das Produkt und das Design des Nuvita 1165 Digital Bottle Warmer sind Warenzeichen von

O produto e design do aquecedor digital de garrafas Nuvita 1165 são marcas registradas da

To προϊόν και ο σχεδιασμός Nuvita 1165 Digital Bottle Warmer είναι εμπορικά σήματα κατατεθέντα

Anteprima Brands International,  
1, St. Luke's Street, Gwardamangia, PTA1020 Pieta, Malta, Europe.  
www.nuvitababy.com

Fabbricato in Cina. Fabricado en China. Made in China. Fabriqué en Chine.  
In China hergestellt. Fabricado na China. Κατασκευάζεται στην Κίνα.

Home use: 220V-240V / 320 Watts  
Car use: 12V/100 Watts